

1. Tools Mode

KEY POINT: *Some features or options described in this chapter may not display or be selectable depending on the configuration of your machine.*

Overview

The Tools Mode enables you to establish the default settings for your DocuColor 2060/2045 digital press with scanner to fit your individual requirements. You can change the settings for a variety of features, such as the initial screen to display when the press is powered on, the language to display on the Touch Screen, special paper sizes that can be used in certain Paper Trays, timers, audio tone controls, default settings for scanner features, image quality settings, and more.

Entering and Exiting Tools Mode



KEY POINT:

- If you attempt to access the Tools Mode while a job is printing, access to the screens will be delayed until the job completes printing.
- Jobs will queue, but will not print while the Tools Mode is active.
- You cannot access the Tools Mode if the 2060/2045 is in a Fault condition.
- You cannot access the Tools Mode if the Pause key on the Control Panel has been pressed to halt a job. When the job that was stopped has been completed, Tools Mode may be accessed.

Entering Tools Mode

Use the following method to enter the Tools Mode:

123...

- 1 Press the **Access** button on the Control Panel. The **Access Password** Screen appears.
- 2 Use the keypad to enter the Tools Mode password. The default password is five 1s (1 1 1 1 1). For security reasons, only asterisks are displayed on the screen.
- 3 Touch the **Enter** button on the screen. The Pathway Options screen appears, as shown in Figure 1.



NOTE: *It is recommended that you change the Tools password as soon as possible after installing the DocuColor 2060/2045 to prevent unauthorized access to the Tools Mode. The procedure for changing the password is in Chapter 4 of this manual.*




Figure 1. Pathway Options screen

- 4 Touch the **Tools Pathway** button on the screen. The **Machine Defaults 1** screen appears.




Figure 2. Machine Defaults 1 screen

- Touch the Machine Defaults 2 tab to display that screen.




Figure 3. Machine Defaults 2 screen

- Touch the Machine Defaults 3 tab to display that screen.




Figure 4. Machine Defaults 3 screen

- 5** Touch the ***Exit Tools*** button to exit the Tools Mode.

Navigating in Tools Mode

The following table provides tells you how to navigate in Tools Mode by pressing or touching keys or buttons.

Key or Button	Result
Tabs	Allows you to view the options available on that screen.
Enter	Saves any changes you made on the screen.
System Default	Returns the settings on the screen to the factory default settings.
Close	Closes the screen and returns the system to the previous screen.
Off	Deactivates the feature.
Reset	Returns the settings on the screen to the settings that were in effect when the screen opened.
Cancel	Cancels the changes made on the screen.
Exit Tools	Exits the Tools Mode.



NOTE: *Changes made to features in the Tools Mode take effect when you exit Tools Mode.*

Machine Defaults and Feature Defaults

The **Machine Defaults 1** screen appears when you first enter the Tools Mode. You can change the default settings for the options shown on the **Machine Defaults 1**, **Machine Defaults 2**, **Feature Defaults 1**, and **Feature Defaults 2** screens. The **Feature Defaults 2** screen is accessed by touching the **More...** tab.



NOTE: *The Machine Defaults 3 screen is discussed later in this chapter.*

The procedures used to change settings for the options shown on the screens are described in detail after the figures below.




Figure 5. Machine Defaults 1 screen

The *Machine Defaults 2* screen is illustrated in the following figure.




Figure 6. Machine Defaults 2 screen

The *Feature Defaults 1* screen is illustrated in the following figure.




Figure 7. Feature Defaults 1 screen

The Feature Defaults 2 screen is illustrated in the following figure.




Figure 8. Feature Defaults 2 screen



NOTE: *The Service Call feature is not yet available.*

Machine Defaults 1

This section describes the features available to you through the **Machine Defaults 1** screen. You can access the following DocuColor features through the **Machine Defaults 1** screen:

- Initial Screen
- Auto Color Calibration
- Tray Priority
- System Timers
- Audio Tones
- Productivity Setting
- Auto Tray Switching
- Set Date & Time
- Dual Language
- Non-Standard Paper Size
- Oversize Settings



NOTE: *The Tray Priority and Auto Tray Switching features may not be available, depending on your DocuColor software version.*

Touch the **Machine Defaults 1** tab. The **Machine Defaults 1** screen appears.




Figure 9. Machine Defaults 1 screen

Initial Screen

Use the Initial Screen to select the default screen when the DocuColor is powered on. You can choose from three screens:

- Features
- Job Status
- Machine Status



NOTE: *The Basic Features screen is the factory default setting.*

1

Touch the **Initial Screen** button on the **Machine Defaults 1** screen. The **Initial Screen** screen appears.




Figure 10. Initial Screen screen

2 Touch the *Features*, *Job Status* or *Machine Status* button.



NOTE: Refer to the *DocuColor 2060/2045 Operator Manual* for information regarding the features on this screen and regarding the Added Features, Image Quality, and More... screens.

If you leave the setting at the Features screen, the screen shown below appears when the machine is powered on. This screen displays the Basic Features tab for scan to print jobs.




Figure 11. Basic Features screen

If you change the default setting to the Job Status screen, the screen below appears when the machine is powered on. This screen displays all the jobs currently queued for printing.




Figure 12. Job List screen

If you change the default setting to the *Machine Status* screen, the following screen appears when the machine is powered on. The appearance of your *Machine Status* screen depends on the accessories you have connected.




Figure 13. Machine Status screen



NOTE: Refer to the *DocuColor 2060/2045 Operator Manual* for more information about the *Machine Status* screen.

Auto Color Calibration



KEY POINT: *The DocuColor 2060/2045 Color Calibration procedure does not affect the quality of print jobs sent through your Raster Image Processor. It is for scan to print jobs only.*

The DocuColor 2060/2045 has a number of monitoring sensors, as well as feedback and control mechanisms, that are designed to enhance overall calibration stability. Image quality is also automatically adjusted periodically during operation to keep the calibration as close as possible to the initial setup conditions.

The Raster Image Processor (RIP) connected to your digital press with scanner also has calibration procedures that you can use for network jobs.



KEY POINT: *Calibration targets can be printed only on A4 or letter sized paper. Ensure that your IOT has A4 or Letter paper loaded in one of the paper trays.*



KEY POINT: *You should be skilled in color science and calibration procedures before attempting to use the options available on these screens.*

What to know about screening

The digital press with scanner uses an advanced proprietary screening technology to produce the colors, pictures, tints, and shades required to produce high-quality prints.

PG is an abbreviation for Pattern Generator. The R in 200R refers to Rotated Line screen, and the C in 200C and 15C refers to Cluster Dot screen.

The five screening methods and what you should remember about each are described in the following table.

Screening Method	What to Remember
150C (LPI Cluster Dot)	Provides better coverage on rough paper Larger dot provides better color stability Reduces black and other solid color mottle Provides better black coverage due to black toner granularity Dot size is better for impressions containing tints, highlights, and pastels Most suitable for pages requiring careful control of highlights Poorest performance on text
200C (LPI Cluster Dot)	Produces fine rosettes that can better emulate offset lithography. May leave jaggies on text (fonts) Better for creating smooth gradients with minimum contouring Best for graphics and images Switch to the 200R screen if banding occurs
200R (LPI Rotated Line screen)	The angle is fixed and cannot be adjusted Has vertical screening for black, which is better for text and line art. Switch to the 200C screen if banding occurs. Best all-purpose screen.
300 LPI Line screen	Generally considered a special use screen. Better edges on colored text with fewer jaggies. Poor color stability due to small size of dot. The entire color gamut must be reproduced in two-micron area.
600 LPI Line screen	Least color stability due to small size of dot. Not recommended for most workflows. Used primarily for testing.

The Raster Image Processor uses information from the PostScript job and the software print driver to determine which screen is used for a particular job.

To access the calibration procedures:

123...

- 1 Touch the **Auto Color Calibration** button on the **Machine Defaults 1** screen. The **Auto Color Calibration** screen appears.




Figure 14. Auto Color Calibration screen

From this screen, you can perform the following tasks:

- Run Calibration
- Check Gradation
- Manual Adjust



KEY POINT: Touch the **Reset** button on the **Auto Color Calibration** screen to return any settings you changed to their last saved values. Once you exit **Tools Mode**, any changes you have made are set.

Refer to the following procedures for detailed information regarding each option displayed on this screen.

Run Calibration

Use the Run Calibration feature if it is visually obvious that the gray balance on your scan to print jobs is not correct. During the Run Calibration procedure, the digital press creates a Look Up Table by reading the 12 Toner Density Patches that print out. The digital press then compares those readings to the factory-set target values and makes the necessary adjustments to bring the values within the target range.



NOTE: *PG is an abbreviation for Pattern Generator. The R in 200R indicates Rotated Line screen, and the C in 200C and 150C indicates Cluster Dot screen.*



1

Touch the **Run Calibration** button on the **Auto Color Calibration** screen to begin the calibration process. The **Run Calibration** screen appears.




Figure 15. Run Calibration screen

2

Do one of the following:

- Touch the **300 PG** button to calibrate the 300 Line screens (200R, 200C, and 150C screens). Use this option only if you have noticed a problem with halftone screening.
- Touch the **600 PG** button to calibrate the 600 Line screen. Use this option only if you have noticed a problem with the gray scale on text.
- Touch the **300 PG & 600 PG** button to calibrate all the screens.

3

Press the **Start** button on the Control Panel. The calibration process starts and color patch prints are printed.

Check Gradation

The Check Gradation feature allows you to print gradated color patch prints for each line screen on the digital press. These gradated color patch prints are used to verify that the dry ink/toner densities for CMYK and Grey balance are correct. If you are dissatisfied with the appearance of any color on the print, you can manually adjust the dry ink/toner densities for Cyan, Magenta, Yellow, and Black using the Manual Adjust feature. It is recommended that you begin your calibration by calibrating the 300 PG screen first. This is the basic line screen that is used, and all other line screens are calibrated against the 300 PG screen.

Use this feature daily and compare the output of gradated color patches to the color patch prints from the previous day. Under normal operating conditions, there should be no difference between them. Automatic sensors and control mechanisms in the digital press with scanner should maintain consistent calibration.

If there is an obvious visual difference between two days' color patches, run the calibration process on the Raster Image Processor, then run this gradation process again.

123...

- 1 Touch the **Check Gradation** button on the **Auto Color Calibration** screen to begin the process. The **Check Gradation** screen appears.




Figure 16. Check Gradation screen

- 2 Touch the button for the screen for which you want to check the gradation.
- 3 Press the **Start** button on the Control Panel. The gradation check process starts and gradated color patch prints are printed.
- 4 Repeat the process for each screen for which you want to check the gradation.

Manual Adjust

The Manual Adjust feature enables you to modify each color (CMYK) for Low, Mid, and High densities. You can also modify the same settings for the highlight values of each screen.



KEY POINT: *Manual Adjust should be used only by an expert in color science. Any changes made on this screen remain in effect for all future scanned jobs, until it is changed again.*



- 1 Touch the **Manual Adjust** button on the **Auto Color Calibration** screen. The **Manual Adjust** screen appears.




Figure 17. Manual Adjust screen

The value displayed for each setting, 128, is the mid point between 0 and 255. Entering a lower number produces a lighter color. Entering a higher number produces a darker color. If you make any changes, run test prints to evaluate the output prints.

2 Follow the directions on the screen and touch the button for the value you wish to adjust.

3 Touch the up or down arrow buttons until the value you want is displayed in the field above the arrow buttons.



KEY POINT: *You should not adjust the value more than 5 counts at a time.*

4 Touch the **Enter** button on the screen.

5 Repeat steps 2, 3, and 4 to enter other new values.

6 Press the **Start** button on the Control Panel to enter the new values into the system.



KEY POINT: *It is recommended that you run the Check Gradation procedure for the screening type that you are adjusting. Do a before and after comparison to verify your changes.*

Tray Priority

The Tray Priority feature allows you to select priorities for each paper tray. If the Auto Tray Switching feature is enabled, and each paper tray contains the same size and weight paper, the digital press feeds paper from the paper tray set at Priority 1. If there is no paper in the Priority 1 paper tray, the Priority 2 paper tray is automatically selected, and so on.



KEY POINT: *Depending on your software version, the Tray Priority feature may not be available. This feature must be enabled by a Xerox Service Representative using the correct version of software.*

123...

- 1 Touch the **Tray Priority** button on the **Machine Defaults 1** screen. The Tray Priority screen appears.




Figure 18. Tray Priority screen

- 2 Touch the desired Priority button in the Priority column.
- 3 Touch the button for the Paper Tray that will have that priority. The number of the selected Paper Tray appears next to that Priority button.
- 4 Repeat this procedure for each Priority. You will not be able to set the same Paper Tray at more than one Priority at a time.
- 5 Touch the **Close** button to return to the **Machine Defaults 1** screen. You will not be able to touch the Close button until you have set Paper Trays for each Priority.

System Timers

The System Timers feature allows you to change the factory default settings for the timers in the digital press with scanner.

To access the various timers, touch the **System Timers** button on the **Machine Defaults 1** screen.

The **System Timers** screen appears. From this screen you can view the time currently set for each of the timers, and select the one you want to change.




Figure 19. System Timers screen

Power Saver

Use this feature to set the time that elapses until the digital press with scanner enters a reduced power consumption mode. This timer is activated when all print jobs have been completed and there are no jobs in the job queue.

The digital press with scanner exits the Power Saver mode when a job is sent to be printed.

123...

- 1 Touch the **Power Saver** button on the **System Timers** screen. The **Power Saver** screen appears.




Figure 20. Power Saver screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 240 minutes.
To use the system default time of 60 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Screen Saver

The Screen Saver feature allows you to protect the screen from being damaged with permanent marks if the digital press with scanner is idle for a period of time.

123...

- 1 Touch the **Screen Saver** button on the **System Timers** screen. The **Screen Saver** screen appears.




Figure 21. Screen Saver screen

- 2 Use the up or down arrow buttons to change the time. The range available is 10 to 60 minutes.
To use the system default time of 10 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Job Spacing

Use the Job Spacing feature when there are multiple jobs queued and you would like to allow 7 seconds to unload prints from a finishing device before the next job starts printing.

123...

- 1 Touch the **Job Spacing** button on the **System Timers** screen. The **Job Spacing** screen appears.




Figure 22. Job Spacing screen

- 2 Touch the **7 Seconds** button to enable the feature or touch the **Off** button to disable the feature.
- 3 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Tools Off

Use the Tools Off feature to have the digital press with scanner automatically return to the printing or scanning mode when no action has been taken on the Tools Mode screens after the set amount of time.



KEY POINT: *Jobs sent over a network will queue but will not print while the Tools Mode is active.*



- 1 Touch the **Tools Off** button on the **System Timers** screen. The **Tools Off** screen appears.




Figure 23. Tools Off screen

- 2 Use the up or down arrow buttons to change the time. The range available is 10 to 60 minutes.
To use the system default time of 10 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Auto Resume Scan

Use the Auto Resume feature to restart a copy job automatically after a fault is cleared and a scanned job is waiting for user instruction, or to restart a copy job waiting for user instruction after the Job Interrupt button on the Control Panel has been pressed.

123...

- 1 Touch the **Auto Resume Scan** button on the **System Timers** screen. The **Auto Resume Scan** screen appears.




Figure 24. Auto Resume Scan screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Auto Resume Print

Use the Auto Resume Print feature to restart a job automatically after a fault is cleared and a job received over the network is waiting for user instruction, or to restart a job waiting for user instruction after the Interrupt button on the Control Panel has been pressed.

123...

- 1 Touch the **Auto Resume Print** button on the **System Timers** screen. The **Auto Resume Print** screen appears.




Figure 25. Auto Resume Print screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Auto Resume Stop

Use the Auto Resume Stop feature to restart a job automatically after the Pause button on the Control Panel is pressed and the job is waiting for user instruction.

123...

- 1 Touch the **Auto Resume Stop** button on the **System Timers** screen. The **Auto Resume Stop** screen appears.




Figure 26. Auto Resume Stop screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Auto Resume Hold

Use the Auto Resume Hold feature to automatically proceed to print the next job in the queue if the job currently printing is waiting for user instruction to clear a certain type of fault.

123...

- 1 Touch the **Auto Resume Hold** button on the **System Timers** screen. The **Auto Resume Hold** screen appears.




Figure 27. Auto Resume Hold screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Auditron Mode Off

Use the Auditron Mode Off feature to set the time that it takes the digital press to return to the initial Password screen after the cessation of user activity while in Auditron Mode.

123...

- 1 Touch the **Auditron Mode Off** button on the **System Timers** screen. The **Auditron Mode Off** screen appears.




Figure 28. Auditron Mode Off screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Job Complete

The Job Complete feature determines when the digital press returns to the system default settings after a scanned job with programmed settings is complete. If a user has completed a job and failed to return the system settings to their default values by pressing the **Clear All** button on the Control Panel, the machine automatically restore the default settings after the amount of time set in the Job Complete screen.

123...

- 1 Touch the **Job Complete** button on the **System Timers** screen. The **Job Complete** screen appears.




Figure 29. Job Complete screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen, or select another timer to change.

Job Program Incomplete

The Job Program Incomplete feature allows users to set the time that it takes the digital press to return to the default feature settings after features buttons have been selected to program a job, but the job has not been started and no user activity has occurred for the amount of time selected.

123...

- 1 Touch the **Job Program Incomplete** button on the **System Timers** screen. The **Job Program Incomplete** screen appears.




Figure 30. Job Program Incomplete screen

- 2 Use the up or down arrow buttons to change the time. The range available is 1 to 10 minutes.
To use the system default time of 2 minutes, touch the **System Default** button.
- 3 Touch the **Enter** button on the screen to enter the new time into the system.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen.

Audio Tones

There are three types of audio tones that can be activated on the digital press with scanner, as shown in the following table.

Tone	What the Tone Indicates
Attention Tone	An unselectable button has been touched.
Button Selection Tone	A selectable button has been touched.
Fault Tone	The press is in a fault condition and cannot continue printing.

Each of these tones can be deactivated or set to Soft, Normal, or Loud. The factory default setting is Normal.



- 1
- Touch the **Audio Tones** button on the **Machine Defaults 1** screen. The Audio Tones screen appears.




Figure 31. Audio Tones screen

- 2** Touch the button for the desired volume setting for each tone. To deactivate a tone, touch the **Off** button for that tone.
- 3** Touch the **Reset** button to restore the factory default setting for the three tones.
- 4** Touch the **Close** button to return to the **Machine Defaults 1** screen.

Productivity Setting



KEY POINT: *If you have a DocuColor 2045, this feature is not available.*

Use this setting to optimize the throughput speed for the type of paper you run most frequently. Productivity Setting Feature options are provided in the following table.

Selection	What this Selection Does
Auto	Selects a Fuser temperature based on the paper weight selected in the paper tray, improving average power consumption, but slower operation while waiting for the Fuser to either heat up or cool down
Light Weight	Sets the Fuser temperature to 160°C, which optimizes the throughput speed for light weight papers, and uses lower power consumption
Heavy Weight	Sets the Fuser temperature to 175°C, which optimizes the throughput speed for heavier papers, and results in higher power consumption

123...

- 1 Touch the **Productivity Setting** button on the **Machine Defaults 1** screen. The **Productivity Setting** screen appears.




Figure 32. Productivity Setting screen

- 2 Select the button for the type of paper you use most frequently in the digital press with scanner, or select **Auto** to use the throughput speed for the paper weight selected on the Paper Tray Weight Indicator.
- 3 Touch **Close** to return to the **Machine Defaults 1** screen.

Auto Tray Switching

This feature allows you to set the default settings for the Auto Tray Switching, Auto Paper Selection, and the Inhibited Tray options.

Default Setting	What the Default Does
Auto Tray Switching	Allows the digital press to automatically select another paper tray, containing the appropriate paper, if the selected paper tray becomes unusable
Auto Paper Selection	Allows the digital press to automatically select the appropriate paper size for the job being processed, without a specific paper tray being selected
Inhibited Tray	Allows you to select a specific paper tray, or trays, that you want the digital press to bypass, regardless of the Tray Priority settings



KEY POINT: *Depending on which version of software you have installed, the Auto Tray Switching feature may not be available. This feature must be enabled by a Xerox Service Representative using the correct version of software.*

123...

- 1 Touch the **Auto Tray Switching** button on the **Machine Defaults 1** screen. The **Auto Tray Switching** screen appears.




Figure 33. Auto Tray Switching

- 2 Touch the **Enable** or **Disable** button for the Auto Tray Switching option.
- 3 Touch the **Enable** or **Disable** button for the Auto Paper Selection option.
- 4 To instruct the digital press to bypass one or more of the paper trays, touch the desired Paper Tray button in the Inhibited Tray column.
To deselect a paper tray, touch that Paper Tray button again.
To return the settings to the last saved values, touch the **Reset** button.
- 5 Touch the **Close** button to return to the **Machine Defaults 1** screen.



NOTE: A button for Tray 4 appears only if you have this optional accessory connected to your digital press.

Transparency Size

Use the Transparency Size button to change the default size for printing on transparencies. Your options are 8.5x11.0" and 8.3x11.7" (or A4).

123...

- 1 Touch the **Transparency Size** button on the Machine Defaults 1 screen. The **Transparency Size** screen appears.




Figure 34. Transparency Size screen

- 2 Select one of the sizes displayed for the default transparency size.
- 3 Touch the **Close** button to return to the **Machine Defaults 1** screen.



NOTE: You can also set the transparency size by adjusting paper guides in the paper trays. The machine uses the size defined by the paper tray guides only if the Transparency Options feature is not selected.

Set Date & Time

Use the Set Date & Time feature to set the date and time for the system. The date and time is displayed on the **Error Log** screen and on the **Date and Time** screens.

Setting the Date

123...

- 1 Touch the **Set Date & Time** button on the **Machine Defaults 1** screen. The **Set Date and Time** screen appears with the Set Date button selected and options for setting the date displayed on the right.




Figure 35. Set Date screen

- 2 Select the date format you wish to use.
 - 3 Use the up or down arrow buttons to enter the correct year, month, and day.
 - 4 Touch the **Enter** button on the screen to save your selections.
- The next time you enter the Tools Mode, the date that you set is displayed.

Setting the Time

123...

- 1 Touch the **Set Date & Time** button on the **Machine Defaults 1** screen. The **Set Date and Time** screen appears with the Set Date button selected and options for setting the date displayed on the right.
- 2 Touch the **Set Time** button. Options for setting the time appear in the Set Time screen.




Figure 36. Set Date & Time screen with Set Time button selected

- 3 Touch the **12 Hour Clock** or the **24 Hour Clock** button.
- 4 Use the up or down arrow buttons to set the correct hour and minutes. If you selected the 12 Hour Clock, touch the **AM** or **PM** button.
- 5 Touch the **Enter** button on the screen to save your selections. The next time you enter the Tools Mode, the time that you set will be displayed.
- 6 Touch the **Close** button to return to the **Machine Defaults 1** screen.

Dual Language

This feature enables you to set one of two available languages as the default for the Touch Screen. When your DocuColor 2060/2045 was installed, your Xerox service representative loaded onto your system your choice of two languages that you can choose from to be displayed on the Touch Screen.



- 1** Touch the *Dual Language* button on the *Machine Defaults 1* screen.
- 2** Touch the button for the default language you want to appear on the Touch Screen.

After exiting the Tools Mode, you can switch the Touch Screen to the other language by pressing the ***Dual Language*** button on the Control Panel.

- 3** Touch the ***Close*** button to return to the ***Machine Defaults 1*** screen.




Figure 37. Dual Language screen

Non-Standard Paper Size

You can run non-standard sized paper from Trays 3 and 4 by entering the paper size on the Non-Standard Paper Size screen for the tray being used. Tray 4 is optional equipment; therefore the Tray 4 button appears on the screen only if Tray 4 is connected to the DocuColor 2060/2045.



KEY POINT: *Be sure to select **Non-Standard Size** on the top front of the tray, and use the **Paper Weight Indicator** at the right side of the tray to select the paper weight being used.*



- 1 Touch the **Non-Standard Size Paper** button on the **Machine Defaults 1** screen. The **Non-Standard Paper Size** screen appears.




Figure 38. Non-Standard Paper Size screen

- 2 Touch the desired Paper Tray button on the **Non-Standard Paper Size** screen.
- 3 Use the up or down arrow buttons on the screen to enter the X and Y dimensions of the paper being used in the tray. The dimensions shown on the screen above the X and Y boxes indicate the minimum and maximum sizes you can enter.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen.
- 5 To use these settings, exit the Tools Mode and ensure that **Non-Standard Size** has been selected on the top/front of the tray.

Oversize Settings

You can use Trays 1 and 2 to run 12 x 18 inch or SRA3 (12.6 x 17.7 inch, 320 x 450 mm) paper by having your Xerox representative remove the side paper guide on the paper tray, then selecting the tray and the paper size on this screen.

123...

- 1 Touch the **Oversize Settings** button on the **Machine Defaults 1** screen. The **Oversize Settings** screen appears.




Figure 39. Oversize Settings screen

- 2 Touch the **Tray 1** or **Tray 2** button on the **Oversize Settings** screen.
- 3 Touch the button for the oversize paper you want to run in the tray.
- 4 Touch the **Close** button to return to the **Machine Defaults 1** screen.
- 5 To use these settings, exit the Tools Mode and run the job from the tray programmed.

Machine Defaults 2

This section describes the features available to you through the **Machine Defaults 2** screen. You can access the following DocuColor features through the **Machine Defaults 2** screen:

- Paper Registration Adjustment
- 100% Adjust
- Special Tray
- Additional Originals
- Stored Program Access
- Auto Recognition
- Reduce/Enlarge Presets
- Photo Reproduction Level
- Color Adjust & Registration
- Auto Rotation
- Maximum Scan To Print Quantity
- Decurler Setup

Select the **Machine Defaults 2** tab, and the **Machine Defaults 2** screen appears.




Figure 40. Machine Defaults 2 screen

Paper Registration Adjustment

Use the Paper Registration Adjustment feature when running duplex jobs to adjust the image position if the registration is not correct.

Image adjustment may be necessary for a couple of reasons:

- Paper is not always the exact same size. It may vary slightly, with differences of plus or minus 1mm, causing the image to be misregistered. To reduce the possibility of size differences, it is recommend that you use paper from the same lot when running duplex jobs.
- During the fusing process, the heat and pressure applied to the paper causes the paper to stretch. If the images on sides one and two are the same size, the stretching of the paper will cause the image on side one to be slightly larger than the image on side two.



Some RIP manufacturers have a paper registration feature that you can also use to adjust the position of the image on the paper. Refer to the documentation that came with your RIP.

Use the following procedure to adjust for side one/side two registration problems:



1

Prepare the image, or images, by noting a reference point on side one, or by placing registration marks at the image border. You can use a reference point within the image or at the corner of the image.



KEY POINT: *Remember that the digital press does not print bleed edge images.*

2

Output 10 duplex prints and compare the registration mark or reference point on side one to side two. Discard the first few prints, as inconsistency tends to be greater with these images. If there is misregistration, continue with this procedure.

3

Measure the distance between the registration point and the edge of the paper on both the lead edge (Y) of the paper and the side edge (X).

Refer to the Measuring Misregistration figure below. The solid line registration marks indicate the reference point on side one. The dotted lines indicate the reference point on side two.




Figure 41. Measuring Misregistration

- 4 Access Tools Mode and touch the **Paper Registration Adjustment** button on the **Machine Defaults 2** screen. The **Paper Registration Adjustment** screen appears.




Figure 42. Paper Registration Adjustment screen

- 5 Select either the **Side 1** or **Side 2** button to adjust the registration.



KEY POINT: Use the **Oversize Paper Offset** button only for papers larger than long edge feed, 8.5x11 inch or A4 paper. Refer to Step 8 if using this option.

- 6 On the next screen, select the tray from which the paper is feeding.




Figure 43. Paper Registration Adjustment screen



NOTE: *The button for Tray 4 does not appear unless you have this optional accessory connected to your DocuColor 2060/2045.*

7

Use the up or down arrow buttons to enter the amount of adjustment for either edge or both edges.



KEY POINT: *Remember that the Lead Edge Registration adjustment is the feeding edge, or Y direction. The Side Edge Registration adjustment is the front to back, or X, direction.*

KEY POINT: *If the reference point on side two is closer to the edge of the paper compared to the reference point on side one, enter a plus figure. If the reference point on side two is further from the edge of the paper compared to side one, enter a minus figure.*

KEY POINT: EXAMPLE: *If the measurement is 1.2mm closer to the edge of the paper, enter +1.2mm.*

- 8 If you selected the **Oversize Paper Offset** button to adjust the registration on paper larger than 8.5x11 inch or A4 LEF, the following screen appears.




Figure 44. Paper Registration Adjustment screen

- 9 Touch the **Offset Level 1, 2, 3, or 4** button to adjust the position of the paper as it feeds. Refer to the following table for the adjustments made for each Offset Level.

Paper Size	Level 1	Level 2	Level 3	Level 4
310mm	10.0mm	10.0mm	10.0mm	10.0mm
311mm	9.5mm	9.5mm	9.5mm	9.5mm
312mm	9.0mm	9.0mm	9.0mm	9.0mm
313mm	8.5mm	8.5mm	8.5mm	8.5mm
314mm	8.0mm	8.0mm	8.0mm	8.0mm
315mm	7.5mm	7.5mm	7.5mm	8.0mm
316mm	7.0mm	7.0mm	7.0mm	8.0mm
317mm	6.5mm	6.5mm	7.0mm	8.0mm
318mm	6.0mm	6.0mm	7.0mm	8.0mm
319mm	5.5mm	6.0mm	7.0mm	8.0mm
320mm	5.0mm	6.0mm	7.0mm	8.0mm

100% Adjust

Use the 100% Adjust feature to fine tune the 100% magnification value on your digital press with scanner. The available adjustment range is from 98.0% to 102.0%.

123...

- 1 Touch the **100% Adjust** button on the **Machine Defaults 2** screen. The 100% Adjust screen appears.




Figure 45. 100% Adjust screen

- 2 Use the up or down arrow buttons to set the desired percentage for the x value. The available range is 98.0% to 102.0%.
- 3 Use the up or down arrow buttons to set the desired percentage for the y value. The available range is 98.0% to 102.0%.
- 4 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Special Tray

Use the Special Tray feature to select a default tray that holds special materials for each of the following features:

- Covers
- Inserts
- Transparency Dividers
- Booklet Creation



NOTE: For more information on Covers, Inserts, Transparency Dividers, and Booklet Creation, please see the DocuColor 2060/2045 Digital Color Press Operator Manual.



- 1 Touch the **Special Tray** button on the **Machine Defaults 2** screen. The **Special Tray** screen appears.




Figure 46. Special Tray screen

- 2 Select the tray to which you want the machine to default when printing on special materials.

NOTE: If you select **Transparency Dividers**, **Tray 3** becomes unavailable.

- 3 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Additional Originals

Use the Additional Originals feature to scan, into one job, documents that have different programming requirements, or documents that must be scanned from different input areas. The original documents may be scanned using the Platen Glass, the DADF, or a combination of both.

The following are examples of jobs that require the use of Additional Originals:

- The job contains too many pages to be placed on the document handler at one time.
- The job contains documents that must be programmed separately for any of the following reasons:
 - The input documents are of different sizes, types, or color settings.
 - The output requires different size, type, or color stocks.
 - There are image quality requirements on some pages.

123...

- 1 Touch the **Additional Originals** button on the **Machine Defaults 2** screen. The **Additional Originals** screen appears.




Figure 47. Additional Originals screen

- 2 Touch the **On** or **Off** button.
- 3 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Stored Program Access

Use the Stored Program Access feature to specify whether you want users to be able to store and recall jobs, or to just recall jobs.

123...

- 1 Touch the **Stored Program Access** button on the **Machine Defaults 2** screen. The **Stored Program Access** screen appears.




Figure 48. Stored Program Access screen

- 2 Touch the button for **Store and Recall** or **Recall Only**.
- 3 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Auto Recognition

The Auto Recognition feature allows you to define the range for recognition between Text: Photo and Black & White: Color content in a scanned original by setting the default to favor the type of documents that are scanned most frequently. Each option allows you to select from five levels of discrimination, which are described in the following table.

Content Type	Levels
Text: Photo	Level 5: Use this setting when scanned originals contain more Photo than Text
	Level 3: Use this setting when scanned originals contain equal amounts of Text and Photo
	Level 1: Use this setting when scanned originals contain more Text than Photo
Black & White: Color	Level 5: Use this setting if you wish the digital press to discriminate more toward Color than Black & White scan to print images.
	Level 3: Use this setting if you wish the digital press to discriminate equally between Color and Black & White scan to print images.
	Level 1: Use this setting if you wish the digital press to discriminate more toward Black & White than Color scan to print images.

123...

- 1 Touch the **Auto Recognition** button on the **Machine Defaults 2** screen. The **Auto Recognition** screen appears.




Figure 49. Auto Recognition screen

- 2 Touch the **Text: Photo** or **Black & White: Color** button. Auto Photo & Text levels appear to the right of the Auto Recognition screen.




Figure 50. Text: Photo screen




Figure 51. Black & White: Color screen

- 3 Touch the button for the desired level on the popup screen. The available levels are 1 to 5.
- 4 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Reduce/Enlarge Presets

Use the Reduce/Enlarge Presets feature to change the factory set default for the preset reduce and enlarge percentages that are available for the Reduce/Enlarge feature. The percentage can be changed to one of the available fixed magnifications, or you can change the variable preset percentage to whatever percentage between 25% and 400% you desire.

123...

- 1 Touch the **Reduce/Enlarge Presets** button on the **Machine Defaults 2** screen. The **Reduce/Enlarge Presets** screen appears.




Figure 52. Reduce/Enlarge Presets screen

- 2 Touch the button for the desired **Preset** percentage. Preset values appear on the **Reduce/Enlarge Presets** screen.




Figure 53. Preset Percentages screen

To change the preset value shown on these buttons, touch the desired fixed percentage button from the above screen.

- 3 If you select the **Variable** preset, use the up or down arrow buttons, shown on the popup screen on the next page, to enter the desired percent value. The available range is 25% to 400%.




Figure 54. Variable Preset Screen

- 4 Touch the **Close** button to return to the **Machine Defaults 2** screen.



NOTE: The percentages shown on the above screen may vary depending on your market area.

Photo Reproduction Level

Use the Photo Reproduction Level feature to adjust the reproduction level on your digital press with scanner. Each reproduction level varies in the definition of halftone effect and text effect. Select a default level that represents the type of image that is most frequently scanned.

Optimize Photo adjusts for a more defined halftone effect and a less defined text effect.

Optimize Text adjusts for a less defined halftone effect and a more defined text effect.

123...

- 1 Touch the **Photo Reproduction Level** button on the **Machine Defaults 2** screen. The **Photo Reproduction** screen appears.




Figure 55. Photo Reproduction screen

- 2 Touch the button for the desired reproduction level.
- 3 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Color Adjust & Registration

The Color Adjust & Registration feature allows you to define the 29 default colors that are available on the **Basic Features** screen, in the Single Color Option. The color selection available on the **Single Color Palette** screen can be changed by adjusting the density of Cyan, Magenta, and Yellow. The table below lists the factory default settings for each color. They are organized according to the order in which the buttons appear on the **Color Adjust & Registration** screen.

Color No.	C	M	Y	Color No.	C	M	Y	Color No.	C	M	Y	Color No.	C	M	Y
1	0	0	10	9	100	51	0	17	51	14	34	25	3	64	58
2	2	48	100	10	100	32	22	18	6	3	20	26	30	32	0
3	0	100	63	11	100	6	54	19	20	34	12	27	49	21	8
4	6	100	0	12	83	0	100	20	0	0	0	28	37	22	0
5	27	100	0	13	49	4	100	21	34	5	0	29	65	100	21
6	50	80	0	14	15	8	100	22	30	3	27				
7	59	70	0	15	99	50	99	23	2	35	23				
8	70	62	13	16	14	3	15	24	32	34	5				

123...

- 1 Touch the **Color Adjust & Registration** button on the **Machine Defaults 2** screen. The Color Adjust & Registration screen appears.




Figure 56. Color Adjust & Registration screen

- 2 Touch the desired color button to display the default setting.
- 3 Use the up or down arrow buttons to adjust the values for Cyan, Magenta, and Yellow. The available range is 0 to 100%.
- 4 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Auto Rotation

The Auto Rotation feature allows you to turn on automatic rotation. Auto Rotation rotates the original image so it is in the same orientation as the selected output paper. This feature, if it is turned on, is useful in correcting any inconsistencies in image orientation. The following options are available on this screen:

Details - select the paper selection method:

- Auto Paper Selection (APS) & Auto R/E (Reduce/Enlarge)
- APS & Tray Select & Auto R/E

Confirm Settings - confirm the settings you have chosen.

- Auto R/E - You are prompted to confirm the rotation if Auto% is selected under Reduce/Enlarge on the **Basic Features** screen.
- Tray Select - You are prompted to confirm the rotation if you have selected a specific paper tray on the **Basic Features** screen. This appears on the **Auto Rotation** screen only if you have selected APS & Tray Select & Auto R/E.



NOTE: *Depending on your software version, the Auto Paper Selection option may not be enabled. In this case, the Auto Rotation feature ignores Auto Paper Selection. The Auto Rotation feature does work for Auto Reduce/Enlarge and Tray Select with all versions of software.*

123...

- 1 Touch the **Auto Rotation** button on the **Machine Defaults 2** screen. The **Auto Rotation** screen appears.




Figure 57. Auto Rotation screen with APS & Auto R/E screen button selected

- 2 Touch the **On** or **Off** button.

- 3 If you selected **On**, touch the button for either **APS & Auto R/E** or **APS & Tray Select & Auto R/E** on the popup screen. See the screen above for the **Auto Rotation screen** with APS & Auto R/E screen button selected. See the screen below for the **Auto Rotation** screen with APS & Tray Select & Auto R/E selected.




Figure 58. APS & Tray Select & Auto R/E screen

- 4 Touch the **On** or **Off** button in the lower-right corner of the screen to confirm your settings for either selection.
- The Tray Select confirmation buttons appear only if you have selected APS & Tray Select & Auto R/E.
- 5 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Maximum Scan to Print Quantity

Use the Maximum Scan to Print Quantity feature to set a limit on the number of copies that can be run for a single scan to print job.

123...

- 1 Touch the **Maximum Scan to Print Quantity** button on the **Machine Defaults 2** screen. The Maximum Scan to Print Quantity screen appears.




Figure 59. Maximum Scan to Print Quantity screen

- 2 Use the numeric keypad to enter the desired maximum number of prints. 9999 is the maximum value that can be set.
- 3 To return the value to its last saved value, touch the **Reset** button.
- 4 Touch the **Close** button to return to the **Machine Defaults 2** screen.

Decurler Setup

Use the Decurler Setup feature to compensate for paper curl in your prints.

Paper curl is caused by many variables:

- The manufacturer's brand of paper and the manufacturing lot.
- The weight of the paper, and if it is coated or uncoated.
- The amount of dry ink/toner and the area being covered on a sheet. The heavier the coverage, the greater the tendency to curl.
- The atmospheric conditions of the room where the paper is stored.
- The atmospheric conditions of the room where the digital press with scanner is located.
- The heat generated during the fusing processes.

The DocuColor 2060/2045 is equipped with an automatic curl control system that uses the variables listed above to determine the amount of pressure needed at different Decurlers to reduce the curl.



KEY POINT: *If you notice that output prints have too much curl, first try flipping over the stack of paper in the paper tray being used. You can also try running the job from a different tray. If curl is still a problem, refer to the tables below for your market area to change the default Decurler settings.*

Decurler Specifications

The Decurler has both top and bottom adjustment arms that apply pressure to the paper based on the selections made on the Decurler Setup screen. The degree of pressure is applied independently to the top and bottom Decurler arms.

Paper Types A, B, and C, shown in the following table, are the parameters established for how papers interact with the DocuColor 2060/2045. Refer to the Recommended Materials List for the recommended settings for grades of paper. Variability from one lot of paper to another may require selecting a different Decurler setting.

Paper Weights	Tray 1	Tray 2	Tray 3 Uncoated	Tray 3 Coated	Tray 4 Uncoated	Tray 4 Coated
64 - 80 g/m ²	A	A	A	A	A	A
81 - 105 g/m ²	A	A	A	B	A	B
106 - 135 g/m ²	B	B	B	A	B	A
136 - 150 g/m ²	A	A	A	A	A	A
151 - 220 g/m ²	A	A	A	A	A	A
221 - 280 g/m ²	N/A	N/A	A	A	N/A	N/A

123...

- 1 Load the Paper Tray with the paper you wish to use for a job. Make the correct paper weight selections on the tray for the paper being used and run a few test prints. If there is too much curl, proceed to step 2.
- 2 On the *Machine Defaults 2* screen, touch the *Decurler Setup* button. The *Decurler Setup* screen appears.




Figure 60. Decurler Setup screen

3

When a Paper Tray on the screen is selected, the default selections for Paper Weight and Paper Type are automatically selected. Touch the number of the Paper Tray from which the paper is feeding.

The button for Paper Tray 4 displays only if this optional tray is connected. The button for 221 - 280 g/m² displays only for Tray 3.

4

If there is still too much paper curl after trying the tips in the Key Point on the previous page, follow the remaining steps in this procedure.



KEY POINT: *Paper Tray 3 accepts paper weights from 64 to 280 g/m². If you select Paper Tray 3 or 4, buttons for Uncoated and Coated are displayed under the Coating heading.*



NOTE: *Your configuration may not show Tray 4.*

If the optional Paper Tray 4 is connected, a button for Tray 4 is displayed under Paper Trays. You may select from any of the displayed paper weights; 64 to 220 g/m², and either coated or uncoated paper. Select the correct paper type if other than Paper Type A. Refer to the tables shown previously in this section for the default settings for various market areas.

5

Touch the **Close** button to save your selections and return to the **Machine Defaults 2** screen. Exit the Tools Mode and run a few test prints to determine if the curl was reduced to a satisfactory level.

If curl is still excessive, access the Tools Mode again and try another Paper Type setting. If you are not successful in reducing the curl, call your Xerox service representative.

6

Touch the **Reset** button on the **Decurler Setup** screen to return to the settings established when you first accessed the screen.

Machine Defaults 3

Select the *Machine Defaults 3* tab, and the *Machine Defaults 3* screen appears.





Figure 61. Machine Defaults 3 screen

NVM Read/Write

Your Xerox service representative uses this feature to change certain system settings. It also may occasionally be used by system administrators.



Under most conditions, this feature is not used by system administrators; however, there are limited circumstances under which this feature is used. These circumstances include:

Carbonless Media Enablement

Carbonless papers are coated with several functional coatings which promote the image transfer through the form set and enable the form sets to separate appropriately after padding with a special adhesive. Each supplier of xerographic carbonless paper has developed their own unique chemistry, which is why the following procedure enabling this application, works best with Xerox Premium Digital Carbonless Paper.

In order to avoid problems when running carbonless media, you may use the NVM Read/Write feature to switch on the Carbonless Media feature in order to reliably run carbonless media



CAUTION: *Do not enter any numbers on this screen other than the ones described in this procedure. Entering and saving numbers, other than the ones described, changes the system settings which may result in a service call to restore the system to the correct settings.*

Use the following procedure to switch on a feature:

123...

- 1 From the NVM Read/Write screen, use the keypad on the Control Panel and enter the **Chain Link Number**.
 - The Chain Link Number for the Carbonless Media is **700 656**.
- 2 After entering the desired Chain Link Number, press the **Start** button on the Control Panel. The UI displays this screen:


Tools Mode.
Use the Keypad to input at Chain-Link number, then press start.

Tools Mode:
Non-Volatile Memory Read / Write Close


Chain Link Number	Current Value	New Value
700-656	0	

Press Start to replace the current Non-Volatile Memory value with the new Non-Volatile Memory value.

- 3 To switch on the carbonless media feature, press the **1** button on the Control Panel keypad. The UI displays the following:



- 4 After entering the New Value number of **1**, press the **Start** button. The UI displays the following screen:



- 5 Touch the **Close** button to save and close your new setting.

6 Exit Tools Mode and run your print job.



KEY POINT: *After running your print job, reenter Tools Mode, NVM Read/Write, and **switch off** the feature. Follow the above steps and use the following setting for the New Value number: To switch **off** the Carbonless Media Enablement feature, enter 0.*

KEY POINT: *To prevent paper jams from occurring with stock types other than the carbonless media, you must switch off the NVM Read/Write feature before running other print jobs.*

Feature Defaults 1

This section describes the features available to you through the **Feature Defaults 1** screen. You can access the following DocuColor features through the **Feature Defaults 1** screen:

- Color Mode
- Paper Supply
- Edge/Center Erase
- Color Shift
- Output
- 2-Sided Output
- Original Type
- Chroma
- Reduce/Enlarge
- Image Shift
- Color Balance
- Lighten/Darken

Select the **Feature Defaults 1** tab, and the **Features Defaults 1** screen appears.




Figure 62. Feature Defaults 1 screen

Color Mode

The Color Mode feature allows you to set the default on the **Basic Features** screen to Auto, Full Color (using Black, Yellow, Cyan, and Magenta), 3 Pass Color (using Yellow, Cyan, and Magenta), or Black. Selecting Auto enables the digital press to determine the color mode to use based on its scan of the original document.

123...

- 1 Touch the **More...** tab in the **Tools Mode** screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Color Mode** button. The **Color Mode** screen appears.




Figure 63. Color Mode screen

- 4 Touch the **Auto**, **Full Color**, **3 Pass Color**, or **Black** button.
- 5 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Paper Supply

The Paper Supply feature allows you to designate the default paper tray for your DocuColor 2060/2045. The button for Tray 4 appears only if you have this optional accessory connected to your digital press.

123...

- 1 Touch the **More...** tab in the Tools Mode screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Paper Supply** button. The **Paper Supply** screen appears.




Figure 64. Paper Supply screen

- 4 Touch the button for the paper tray you would like to use as your default paper tray.
- 5 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Edge/Center Erase

This feature allows you to set the default values for the Border Erase and the Edge Center Erase options, or to turn off Edge Erase. When you are making 2-sided copies, Edge Erase is applied to both sides of the output.

Turning Off Edge Erase

123...

- 1 Touch the **More...** tab in the Tools Mode screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Edge/Center Erase** button. The **Edge Center Erase** screen appears.



Figure 65. Edge Center Erase screen

- 4 Touch the **Off** button.
- 5 Touch the Close button to return to the **Feature Defaults 1** screen.

Border Erase

The Border Erase feature allows you to select the desired amount of the image to be erased on all four edges of the scan to print output. Erasing borders eliminates the shadows that are caused by the document edges during the scanning process.

123...

- 1 Touch the **More...** tab in the Tools Mode screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Edge/Center Erase** button. The **Edge Center Erase** screen appears.
- 4 Touch the **Border Erase** button. Border Erase options appear on the right side of the screen.




Figure 66. Border Erase screen

- 5 Use the up or down arrow buttons to select the desired amount of image to be erased on the borders of the print. The range available is 0 to 50mm.
- 6 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Edge Center Erase

The **Edge Center Erase** feature allows you to independently select the amount of the image you want to erase from the edges of the document. Users who do not want to select Edge Erase values for all four edges of their document at the same time are able to select the Left/Right and Top/Bottom values independently of each other. The Center Erase option allows you to select the desired amount of the image to be erased from the Center of the document. This is useful for erasing the shadows that appear when you are scanning two facing pages of a bound document, for example.

123...

- 1 Touch the **More...** tab in the Tools Mode screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Edge/Center Erase** button. The **Edge Center Erase** screen appears.
- 4 Touch the **Edge Center Erase** button. Edge Center Erase options appear on the right side of the screen.




Figure 67. Edge Center Erase screen

- 5 Use the up or down arrow buttons to select the desired amount of image to be erased from Left to Right, Top to Bottom, and the Center of the copy. The available range for each 0 to 50mm.
- 6 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Color Shift

The Color Shift feature allows you to shift the output color of your digital press.

If you select a shift toward red, the red colors shift toward the yellow hue, the green colors toward the cyan hue, and the blue colors toward the magenta hue. The upper bar shifts toward the left. The picture changes to demonstrate the effect of the color shift. All colors in between these original colors also shift in the same direction.

If you select a shift toward blue, the red colors shift toward the magenta hue, the blue colors toward the cyan hue, and the green colors toward the yellow hue. The upper bar shifts toward the right. The picture changes to demonstrate the affect of the color shift. Again, all colors in between these original colors also shift in the same direction.

123...

- 1 Touch the **More...** tab in the Tools Mode screen.
- 2 Touch the **Feature Defaults 1** tab.
- 3 Touch the **Color Shift** button. The **Color Shift** screen appears.




Figure 68. Color Shift screen

- 4 Use the right or left arrow buttons to select the desired value. The available range is -2 to 2.
- 5 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Output

The Output feature allows you to set the default settings that display on the Output option on the **Basic Features** screen. You may select Auto, Face Up, Face Down, Collated, or Uncollated. Selecting Auto enables the digital press to determine the copy output based on the scan of the original document. If Auto is selected, the output from both DADF and the Platen Glass will be Face Up. If you have a High Capacity Stacker or a High Capacity Stacker Stapler connected to your digital press, you can select which output tray to send your prints to, and whether or not to separate your printed sets. You may choose these options independently.

This section provides instructions for using the Output feature without a finishing device, with a high capacity stacker, and with a high capacity stacker stapler.

Without a Finishing Device

123...

- 1 Touch the **Output** button on the **Feature Defaults 1** screen. The **Output** screen appears.




Figure 69. Output screen

- 2 Touch the **Auto**, **Face Up**, or **Face Down** button.
- 3 Touch the **Collate** or **Uncollate** button.
- 4 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Using a High Capacity Stacker

123...

- 1 Touch the **Output** button on the Feature Defaults 1 screen. The **Output** screen opens.




Figure 70. Output screen with HCS

- 2 Touch the **Auto**, **Face Up**, or **Face Down** button.
- 3 Touch the **Collate** or **Uncollate** button.
- 4 Touch the **Stacker** button. The Stacker screen appears.




Figure 71. HCS Popup screen (Stacker Tray selected)

- 5** To send output to the Stacker Tray, touch the **Stacker Tray** button on the popup screen. To send output to the Top Tray, touch the **Top Tray** button.
- 6** If you selected Stacker Tray, touch the **Offset** button to have the printer automatically separate your sets. Touch the **No Offset** button if you do not want your sets separated.
- 7** Touch the **Close** button to return to the **Feature Defaults 1** screen.

Using a High Capacity Stacker Stapler

123...

- 1 Touch the **Output** button on the **Feature Defaults 1** screen. The **Output** screen appears.




Figure 72. Output screen with HCSS

- 2 Touch the **Auto**, **Face Up**, or **Face Down** button.
- 3 Touch the **Collate** or **Uncollate** button.

- 4 Touch the **Stapler/Stacker** button. The **Stapler/Stacker** screen opens.




Figure 73. HCSS Popup screen (Main Tray selected)

- 5 To send output to the Main Tray, touch the **Main Tray** button on the popup screen. To send output to the Top Tray, touch the **Top Tray** button.
- 6 If you selected Main Tray, touch the **Offset** button to have the printer automatically separate your sets. Touch the **No Offset** button if you do not want your sets separated.
- 7 Touch the **Close** button to return to the **Feature Defaults 1** screen.

2 Sided Output


The 2 Sided Output feature allows you to set the default for the 2 Sided output options on the **Added Features** screen for scan to print jobs. The selections available are described in the following table.

Default Selection	Result
1 to 1 Sided	All single-sided scanned originals will print as single-sided prints
1 to 2 Sided	All single-sided scanned originals will print as duplex prints
2 to 1 Sided	All double-sided scanned originals will print as single-sided prints
2 to 2 Sided	All double-sided scanned originals will print as duplex print


If you select one of the three duplex options, you are asked to define the settings for the orientation of the original scanned images and/or output.

- Portrait

Head to Head




Head to Toe




- Landscape

Head to Head



Head to Toe



123...

- 1** Touch the **2-sided output** button on the **Feature Defaults 1** screen. The **2 Sided Output** screen appears.




Figure 74. 2 Sided Output screen with 1-2 Sided selected

- 2** Touch the **1 to 1**, **1 to 2**, **2 to 2**, or **2 to 1** button. The following screens show the **2 Sided Output** screen with 2 to 2 Sided selected and with 2-1 Sided selected.




Figure 75. 2 Sided Output screen with 2-2 Sided Output selected




Figure 76. 2 Sided Output screen with 2-1 Sided Output selected

3 If you select one of the 2 sided options, select either Head to Head orientation or Head to Toe orientation, as described in the following table.

If you choose...	Then select...
1 to 2 output	Either the Head to Head button or the Head to Toe button to select the orientation of the images on the copies.
2 to 2 output	Either the Head to Head button or the Head to Toe button to select the orientation of the images on the originals. Follow the same procedure to select the orientation of the images on the copies.
2 to 1 output	Either the Head to Head button or the Head to Toe button to select the orientation of the images on the originals. Follow the same procedure to select the orientation of the images on the copies.

4 Touch the **Close** button to return the **Feature Defaults 1** screen.

Original Type

The Original Type option allows you to set the original type default on the *Image Quality* screen. Set the default for the majority of the original documents that you will be scanning or printing. Based on the selection, the digital press automatically makes fine adjustments to optimize the sharpness based on the type of original selected. Original types are described in the following tables.

Default Type	When to Select
Auto Photo & Text	Select this setting when most original documents consist of both text and graphics. This setting allows you to select a default of Photo, Halftone, or Xerographic Copy (all with text) as the original type used in scan to print jobs.
Text	Select this setting when most original documents consist of words with few detailed graphics. This setting allows you to select a default of regular Text or Light Text as the original type used in scan to print jobs.
Photo	Select this setting when most original documents contain halftones or photographs. This setting allows you to select a default of Photo, Halftone, or Xerographic Copy (with no text) as the original type used in scan to print jobs.
Map	Select this setting when most original documents contain intricate drawings that require a number of details to be copied with utmost precision. This setting allows you to select Map as the default original type used in scan to print jobs.



KEY POINT: *If you select either Auto Photo & Text or Photo, you should also select the detail for that original type. The details that can be selected for each of these original types described in Table 5.*

Detail	When to Select
Photograph	Select this option when most original documents will be photographs or extremely fine halftones.
Halftone	Select this option when most original documents will be images that are created using a fine screen that varies the darkness and density of dots that make up the image. Examples of halftone images can be found in magazines and newspapers.
Xerographic Copy	Select this option when most jobs will use a reproduction (copy) as the original document.

123...

- 1 Touch the **Original Type** button on the **Feature Defaults 1** screen. The **Original Type** screen appears.




Figure 77. Original Type screen

- 2 Under the **Auto Photo & Text**, **Text**, **Photo**, or **Map** column headings, select an original type for your default setting.
If you choose the **Auto Photo & Text** or **Photo** original type, specify the default for the kind of photograph or picture originals you will be copying. Touch either the **Photograph**, **Halftone**, or **Xerographic Copy** button to set this feature.
- 3 Touch the **Close** button to return to the **Feature Defaults 1** screen.



NOTE: If the **Black Only** option is selected in the **Color Mode** feature in **Tools Mode**, the **Light Text** option is selectable on this screen. Refer to the **Color Mode** section in this book for more information on how to change the settings in that feature.

Chroma

The Chroma feature allows you to raise or lower the chroma default setting of Normal to achieve more or less color saturation on prints. Chroma adjusts the overall richness of color on the output prints. Chroma, or saturation, is the relative chromaticity, or colorfulness, of a color. The amount of saturation differentiates a color from a gray that has the same value.



- 1 Touch the **Chroma** button on the **Feature Defaults 1** screen. The **Chroma** screen appears




Figure 78. Chroma screen

- 2 Touch the button for the desired amount of chroma, or saturation.
The **High** button reflects the greatest amount of chroma, while the **Low** button reflects the least amount of chroma.
- 3 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Reduce/Enlarge

The Reduce/Enlarge option allows you to set the percentage (100%, Auto, or Preset/Variable) of the default reduction or enlargement that displays on the **Basic Features** screen.

100% or Auto

If you select 100%, the digital press duplicates the output print at the same size as the original document. If you select Auto, the digital press determines the reduction or enlargement percentage to use based on the size of the original document and the selected paper tray.

123...

- 1 Touch the **Reduce/Enlarge** button on the **Feature Defaults 1** screen.




Figure 79. Reduce/Enlarge screen

- 2 Touch either the **Auto** button or the **100%** button.
- 3 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Preset/Variable

If you select Preset/Variable, the digital press reduces or enlarges the original document at the selected value. The default percentages that you set will appear on the Preset/Variable screen, which can be accessed through the **Basic Features, Reduce/Enlarge, More...** screen.

To change the default Preset/Variable percent settings on this screen, access the **Machine Defaults 2, Reduce/Enlarge Presets** screen in Tools Mode.

123...

- 1 Touch the **Reduce/Enlarge** button on the **Feature Defaults 1** screen. The **Reduce / Enlarge** screen appears.




Figure 80. Preset/Variable screen with Preset / Variable selected

- 2 Touch the **Preset / Variable** button. The settings for the Preset/Variable feature appear on the right side of the screen. (See the above figure.)
- 3 Touch the button for the desired preset/variable percentage.
- 4 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Image Shift

The Image Shift feature allows you to set the default for Image Shift in the **Added Features, Image Shift** screen. You can set separate defaults for Side 1 and Side 2 images on the output print. The options available:

Default	When to Select
No Shift	If you select this option, the digital press assumes that the original document is registered in the upper left corner of the document glass.
Auto Center	If you select this option, the original image is centered on the output sheet.
Margin Shift	If you select this option, you may shift the original image, for both Side 1 and Side 2, Left to Right using the horizontal arrow buttons, or Top to Bottom using the vertical arrow buttons. The available range for each shift direction is 0 to 50mm.
Unrestricted Shift	If you select this option, you may shift the original image, for both Side 1 and Side 2, Left to Right using the horizontal arrow buttons. The available range for this direction is 0 to 432mm. You may also shift the original image Top to Bottom using the vertical arrow buttons. The available range for this direction is 0 to 297mm.
Corner Shift	If you select this option, you may shift the original image, for both Side 1 and Side 2, to any side of the output page using the eight different arrow buttons on the screen.

123...

- 1 Touch the **Image Shift** button on the **Feature Defaults 1** screen. The **Image Shift** screen appears.



Figure 81. Image Shift screen

- 2 Touch the button for the desired image shift option. Settings for the image shift option you selected appear on the right side of the screen.
- 3 Do one of the following:
 - If you selected **Margin Shift**, select **Side 1** or **Side 2**. Then touch the **Left/Right** or **Top/Bottom** button. Use the arrow buttons to specify the amount of the image shift. Repeat for the other side, if required.

To set the defaults for Side 2, touch the **Side 2** button. Then, touch the **Side 2 Mirror** or **Side 2 Independent** button. The popup screen allows you to specify the amount of image shift for the Side 2 Independent selection only. Selecting Side 2 Mirror will have the system use the same amount of shift selected for Side 1.




Figure 82. Image Shift screen with Margin Shift and Left/Right buttons selected




Figure 83. Image Shift screen with Margin Shift and Top/Bottom buttons selected

- If you selected the **Unrestricted Shift** button, select **Side 1** or **Side 2**. Then use the horizontal arrow buttons to specify the amount of the image shift from Left to Right. To specify the amount of the image shift from Top to Bottom, use the vertical arrow buttons. Repeat for the other side, if required.




Figure 84. Image Shift screen with Unrestricted Shift selected

- If you selected the **Corner Shift** button, select **Side 1** or **Side 2**. Then use the eight different arrow buttons to shift your original image. Repeat for the other side if required.




Figure 85. Image Shift screen with Corner Shift selected

- 4** Touch the **Close** button to return to the **Feature Defaults 1** screen.

Color Balance

The Color Balance feature allows you to set the default levels for the four process colors (Cyan, Magenta, Yellow, Black) on the *Image Quality* screen. You can set th defaults for areas of high, medium, and low density on the scanned prints. You can also set the default for each density level and each color independently in any combination.



KEY POINT: Remember that adjusting the density of any of the process colors affects the complementary colors that use that color.



- 1 Touch the **Color Balance** button on the *Feature Defaults 1* screen. The Color Balance screen appears.




Figure 86. Color Balance screen

- 2 Touch the button for the color that you want to change.
- 3 Use the up or down arrow buttons to obtain the desired settings for Low, Medium, and High Densities. The available range is -3 to +3.
- 4 Repeat the previous step for each color you want to change.
- 5 Touch the **Close** button to return to the *Feature Defaults 1* screen.

Lighten/Darken

The Lighten/Darken feature enables you to set the default for the Lighten/Darken option on the **Image Quality** screen. Changing this setting adjusts the overall lightness or darkness (density) of the output copy. Select Darken settings for light originals and Lighten settings for dark originals. Selecting Auto enables the digital press to determine the lightness or darkness based on its scan of the original document.

123...

- 1 Touch the **Lighten/Darken** button on the **Feature Defaults 1** screen. The **Lighten/Darken** screen appears.




Figure 87. Lighten / Darken screen

- 2 Adjust the darkness or lightness for the output print using the right or left arrow buttons. The available range is 6 (Darken) to 6 (Lighten). Touch the **Auto** button to have the digital press automatically adjust the copy density level.
If you selected Auto and you want to make manual adjustments, touch one of the arrow buttons. The Lighten/Darken scale appears.
- 3 Touch the **Close** button to return to the **Feature Defaults 1** screen.

Feature Defaults 2

Access the ***Feature Defaults 2*** screen by touching the ***More...*** tab on the ***Machine Defaults1***, ***Machine Defaults 2***, or ***Feature Defaults 1*** screen.




Figure 88. Feature Defaults 2 screen

Sharpness

The Sharpness feature allows you to set the default for the Sharpness option on the **Image Quality** screen. Changing the setting adjusts the amount of image edge definition on scanned prints. Use the sharp levels to increase the amount of edge definition for original documents such as maps, line art, or graphics that have crisp lines. Use the soft levels to decrease the amount of edge definition to scan photographs or any other documents for which softer, less focused, output prints are desired. This option is especially useful when scanning very coarse dot screens.

123...

- 1 Touch the **More...** tab.
- 2 Touch the **Sharpness** button. The **Sharpness** screen appears.




Figure 89. Sharpness screen

- 3 Touch the button for the desired amount of image edge definition. The available range is 2 (Sharpest) to 2 (Softest).
- 4 Touch the **Close** button to return to the **Feature Defaults 2** screen.

