

USB Card Reader Plug-in Installation Guide

Xerox® WorkCentre® 6515 Multifunction Printer
Xerox® VersaLink® Series

Purpose

To use a USB-connected card reader in combination with Xerox Convenience Authentication, certain Xerox devices require the installation of a USB card reader plug-in.

The supported USB card readers listed below require the installation of the cardreader_sig.jar plug-in, included in Cardreader_plugin_with_signature.zip.

Supported USB card readers for the WorkCentre 6515 and VersaLink Series Multifunction Printers include:

Elatec TWN4 MultiTech-P, Elatec TWN4 LEGIC NFC-P, Elatec TWN4 MultiTech-PI Proximity, Elatec TWN3 HID Prox, Elatec TWN3 Multi ISO Proximity, Elatec TWN3 Legic, Elatec TWN3 Multi 125, Elatec TWN Inditag, Elatec TWN iClass, OMNIKEY HID 5427, ID Tech Mini Mag 2, RF Ideas RDR-6081-AKU and RDR-6281-AKU, RF Ideas Mag Stripe Reader, YSoft 125Khz ASK FSK, YSoft Legic Advant, MagTek Mag Stripe, Honeywell 3800, Motorola DS9208, Motorola DS457.

Installation Instructions

1. Extract cardreader_sig.jar from the zip file to a convenient location on your computer.
2. To access the device Embedded Web Service, from a Web browser, enter your device IP address.
3. On the device webpage, select **Log In**, and then log in to the device as **Admin**.
4. Select **System**.
5. Select **Plug-in Settings**.
6. Slide **Plug-in Feature** to the right to the checked position.
7. Select **Restart Now** when prompted.
8. When the system is back online, return to the Plug-In Settings page.
 - a. On the device webpage, select **Log In**, and then log in to the device as **Admin**.
 - b. Select **System**.
 - c. Select **Plug-in Settings**.
9. Select **Add**.
10. Browse to the location of the cardreader_sig.jar file you previously extracted from the .zip file.
11. Select **OK**.
12. Select **Close**.
13. Reboot the printer to activate the plug-in. To reboot, go to the Home page, and then go to the Support page.
14. When the system is back online, return to the Plug-In Settings page.
 - a. Select **Log In**, and then log in to the device as **Admin**.
 - b. Select **System**.
 - c. Select **Plug-in Settings**.
15. Ensure the status for the plug-in Xerox USB Card Reader (CR 3.0.04) is **Activated**.
16. Select **Close**. The plug-in is now ready for use.