

Direct Send Jobs

Use this procedure only if the document is in the process of being transmitted in the Direct Send mode. If the Direct Send job is in the Redial Mode the job is a pending job. Refer to the ***Cancel Job*** key.

1. If the document is being transmitted, press ***Stop***.

Cancel this job?

1. Yes
2. No

2. To cancel the job, press **1**.

The job is cancelled and the document feeds through the scanner.