

## 14 Maintaining the Machine

---

### Replacing the Consumables

---


#### Replacing the Paper

---


When the machine runs out of paper, "PAPER TRAY IS EMPTY" displays and printing stops. Replace the paper using the following procedure:

**To replace the paper:**

1. Open the Paper Tray.




2. Do not fan the paper. Make sure that the corners of paper are neatly aligned.



## Maintaining the Machine

3. Press down the paper pressure plate until it clicks.



4. Insert up to 250 sheets into the paper tray.



### CAUTION

To avoid paper jams, do not exceed the upper limit line on the Paper Guide.

