

Operation Modes

Standby Mode

When the machine is in the Standby Mode, the display indicates the machine status, a prompt for the next operation, or an error message. The following information is displayed:

- **Date and time** — The year, month, day and time (hour and minute) are displayed. Use the Menu Mode to set the date display sequence and the time format.
- **Standby Mode Status** — The Standby Mode Status indicates the machine activity. If “Ready” is displayed, the machine has completed the previous task and is ready to fax or copy. If the Paper Tray becomes empty or open, the Standby Mode Status is replaced with the Paper Tray status.
- **Free Memory** — The percentage of remaining memory available for storing documents is displayed. If no memory is used, 100% is displayed.
- **Load document** — Prompts you to load your document. If a document is loaded in the ADF, this text prompts you to “dial or press copy”.
Enter Depart. code — if dept. code feature is enabled.

Communication Mode

- **Memory Send** — Memory send communications are performed in the background.
- **Direct Send** — The status of a Direct Send operation is displayed.
- **Communication results** — Results of a communication can be printed. (Refer to “Confirming a Transmission” in Chapter 8.)
- **Communication error code** — The result of an error in a communication. (Refer to Chapter 13, “Troubleshooting” for a list of the error codes.)