

The machine dials the number, confirms the connection, and sends the document.

### Automatic Redialing\*

---

When the line of the party you are calling is busy, the machine automatically redials the number according to the redial interval selected.

**Hint:** To change the redial settings, press:



(See Chapter 4, "Redial Count and Interval Default Setting".)

If the line is not connected after the redial attempts, the machine goes into a Transmission Error mode, and you must repeat the transmission procedure.

If the Resend Stored Fax feature is active, the documents are retained in memory and can be resent (see Chapter 8, "Resend Stored Fax Setting".)

### Manual Redial Last Number (On-hook, Off-hook)

---

This redial function enables you to transmit a document to the party of the number last dialed by the operator using the machine.

To redial the last number, a fax number must be stored for resend or you must load a document:

1. Pick up the handset, if available, or press:



**Dial fax number**

**Fax number:**



2. Press **Redial** key. The display indicates the last number dialed and the machine dials the phone number.