

Mailbox Communications

Transmitting a Document to an ITU-T Sub address

Use the following procedure to transmit a document to a sub address:

1. Load the document face down in the Document Tray.
2. Select the desired **Resolution** and **Contrast**.
3. Open the Access Cover and press:

Subaddress
ITU-T



Sub address

1. Done
2. Subaddress (SUB)
3. Select. Polling (SEP)
4. Password (PWD)

4. To transmit a document to a remote fax sub address, press **2** to select SUB.

Sub address

SUB (20 max):



5. Use the numeric keypad to enter the remote sub address and press **Enter**.

Note: To communicate with a remote WorkCentre, obtain and enter the remote ITU-T mailbox number.

6. To enter a password, press **4** to select PWD. Using the numeric keypad, enter the password, if required by the remote machine and press **Enter**.

Note: To transmit to a WorkCentre ITU-T Bulletin Board Mailbox, the remote and local machines must have the same passwords.