

## 9 Cancelling Jobs

---

Jobs on the WorkCentre can be cancelled by pressing the **Job Status** key or the **Cancel Job** key.

Active jobs on the WorkCentre can be cancelled by pressing the **Job Status** key. The **Job Status** key allows you to monitor and cancel the active job being processed.

Pending jobs can be cancelled by pressing the **Cancel Job** key and selecting from the list of pending jobs. The **Cancel Job** key allows you to cancel pending jobs by job type.

Pressing **Stop** alone does not cancel a Memory or Pending job. You must use the **Cancel Job** or **Job Status** keys to initiate the cancel procedure.

### Stop Key

---

The **Stop** key is used to eject the document from the scanner prior to scanning, and to cancel Direct Send jobs.

### Job Status Key

---

The active job can be monitored in the display and cancelled if desired. When you press the **Job Status** key, the job currently being processed is displayed.

To monitor and/or cancel the active job:

1. Press:

*Job Status*




|                    |            |
|--------------------|------------|
| <b>Dialing</b>     |            |
| <b>Job number:</b> | <b>006</b> |
| <b>5551212</b>     |            |

## Cancelling Jobs

2. If you would like to cancel the displayed job, press

*Cancel Job*



**Cancel this job?**

**Job number:**

**010**

**1. Yes**

**2. No**

3. Press **1** to cancel the displayed job, or press **2** to return to the Standby Mode.

The machine returns to the Standby Mode.

## Cancel Job Key


---

Pending jobs can be cancelled as they are confirmed in the display. The Cancel Job key allows you to cancel the following types of jobs:

- **Incoming call** — Cancels a job currently being received.
- **Send** — Cancels an active job or a reserved Memory Send job.
- **Document in ADF** — Cancels a Direct Send job in the Document Tray.
- **Poll** — Cancels a reserved “Polling” job.
- **Document to be polled** — Cancels a “Storing a Document to be Polled” job reserved on your machine to be polled.
- **Send via Relay** — Cancels a reserved Relay transmission initiated by your machine.
- **Relay (station)** — Cancels a Relay transmission initiated by a remote machine where your machine is the Relay Station.
- **Poll a mailbox** — Cancels a “Polling a Remote Mailbox” reception job.
- **Send to mailbox** — Cancels a “Sending to a Remote Mailbox” job.

To cancel a pending job:

1. Press:



**Cancel job**  
**1. Incoming call**  
**2. Send**  
**3. Document in ADF**

**4. Poll**  
**5. Doc to be polled**  
**6. Send via relay**  
**7. Relay (station)**  
**8. Poll a mailbox**  
**9. Send to mailbox**

2. Select the type of job you want to cancel.

To cancel an Incoming Reception, press **1**.

To cancel a Memory Send transmission, press **2**.

To cancel a Direct Send transmission, press **3**. Go to step 4.

To cancel a Polling operation, press **4**.

To cancel a Document Waiting to be Polled, press **5**.

To cancel a Relay transmission, press **6**.

To cancel an Incoming Relay transmission, press **7**.

To cancel a Mailbox Polling operation, press **8**.

To cancel a Send to a Mailbox transmission, press **9**.

**Cancel job**  
**[Enter] to cancel**  
**Previous [ ↑ ]**  
**Next [ ↓ ]**

## Cancelling Jobs

The first pending job of the type selected is displayed.

**Note:** *If no key is pressed within 5 seconds, the first pending job is displayed.*

3. Press the  and  arrow keys to view each pending job of this type.

|                       |   |                        |            |
|-----------------------|---|------------------------|------------|
| Type of job           | → | <b>Poll one number</b> |            |
| Remote number         | → | <b>5551212</b>         |            |
| Time job was reserved | → | <b>May-01-97 05:26</b> |            |
| Job number            | → | <b>Job number:</b>     | <b>043</b> |

4. When the job you want to cancel is displayed, press **Enter**.

|                         |            |
|-------------------------|------------|
| <b>Cancel this job?</b> |            |
| <b>Job number</b>       | <b>043</b> |
| <b>1. Yes</b>           |            |
| <b>2. No</b>            |            |

5. To cancel the displayed job, press **1**.

To exit this mode without cancelling a job, press **2**.

The machine returns to the Standby Mode.

## **Direct Send Jobs**

---

Use this procedure only if the document is in the process of being transmitted in the Direct Send mode. If the Direct Send job is in the Redial Mode the job is a pending job. Refer to the ***Cancel Job*** key.

1. If the document is being transmitted, press ***Stop***.

**Cancel this job?**

1. **Yes**
2. **No**

2. To cancel the job, press **1**.

The job is cancelled and the document feeds through the scanner.

## *Cancelling Jobs*

### **Notes:**