

Resolution & Contrast Setting

The default settings can be changed during a transmit or copy operation by pressing the ***Contrast*** and ***Resolution*** keys on the Control Panel.

The following tables define the available default Contrast and Resolution settings:

Resolution selection	Description
Standard	Use for sending normal text and graphics. Selected when Resolution LED is off.
Fine	Use for documents with small characters (newspaper print, etc.).
Superfine	Use for documents containing very detailed print.

Contrast selection	Description
Normal	Use for documents printed with ordinary image density. Selected when the Contrast LED is off.
Lighten	Use for documents with dark print that need to be adjusted to print lighter.
Darken	Use for documents with light or faint print that need to be adjusted to print darker.

Programming the Machine

To change the Contrast & Resolution:

1. Press:



Resolution
1. Standard
2. Fine
3. Superfine

2. Select the Resolution:

To select Standard, press **1**.

To select Fine, press **2**.

To select Superfine, press **3**.

Contrast
1. Normal
2. Darken
3. Lighten

3. Select the Contrast:

To select Normal, press **1**.

To select Darken, press **2**.

To select Lighten, press **3**.

4. The menu selection screen redisplays. Press **Stop** to return to the Standby Mode.