

Setting the Dial Mode*

Your machine must be set to the dialing mode compatible with your telephone line requirements. The Dial Modes supported are tone and pulse. Pulse is sometimes referred to as rotary dial.

If your machine is connected to a PBX system, you may need to enter a number to access the outside telephone line.

To set the Dial Mode:

1. Press:



Dial mode

1. Tone
2. Pulse

2. Select the Dial Mode.

To select tone, press **1**.

To select pulse, press **2**.

Enter outside number

Call number (10 max):



3. Enter the number required to access an outside line, then press **Enter**. (If no number is required, press **Enter**.)

The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.

* This feature not allowed in all markets.