

Cancelling Relay Group Numbers

To cancel a Relay Group Number:

1. Open the Access Cover and press:

Phonebook
Setup



4

Enter group number
or
[<] Back to previous
[Stop] to complete

2. Using the Numeric Keypad, enter the Relay Group number you want to delete, then press **Enter**.

Enter relay number
1. Delete
2. Retain

3. To delete the Relay Group number, press **1**.

To retain the number information, press **2**.

4. The Enter Group Number screen redispays. Press **Stop** to return to the Standby Mode.

The group relay information stored with that Group Number is cleared.