

Replacing the Drum Unit

The Drum Unit requires replacement when the DRUM LIFE WARNING is displayed.

When the Drum Unit requires replacement, the Fuser Cleaner and Ozone Filter must also be replaced. Do not replace the Drum Unit with one that has been used. The DRUM LIFE WARNING display does not clear if a used Drum Unit is installed.




CAUTION

Do not expose the green Drum to light for more than 3 minutes. Never expose the drum to direct sunlight or touch the drum. Damage or poor print quality may result.

To replace the Drum Unit:

1. Grasp the Top Cover Open Lever and open the Top Cover.



Maintaining the Machine




CAUTION


Always hold the Developer Assembly by the green handles. Do not touch the green drum area or the black toner roller. Do not leave the Drum Unit out of the machine for an extended period.

Touching the drum or exposing the Drum Unit to light could lower the print quality.

2. Remove the Developer Assembly from the machine. The following figure shows how to remove the Developer Assembly.




3. Lift up on the 2 green handles to separate the Drum Unit from the Developer Assembly. The following figure shows the Drum Unit separated from the Developer Assembly.




Maintaining the Machine

4. Place the Developer Assembly on a flat clean surface. Discard of the used Drum Unit properly.
5. Position the new Drum Unit with the green drum surface facing the black toner roller on the Developer Assembly. Without touching the green drum surface, hook the Drum Unit to the Developer Assembly. The following figure shows how to join the Drum Unit and the Developer Assembly.




6. Holding the Developer Assembly by the green handles, align the three shafts on the Developer Assembly sides with the slots in the machine frame. Lower the assembly into the machine.




Maintaining the Machine

The following figure shows how the shafts on the Developer Assembly align with the slots.



028

7. Press firmly on the green squares on the Drum Unit until the Drum Unit clicks into place. The following figure shows how to press the Drum Unit into place.




029

Maintaining the Machine

To replace the Ozone Filter:

8. Remove the Ozone Filter from the inside of the machine. Then, place the new ozone filter into the machine.



9. Close the Top Cover. Press down on the Top Cover until a “click” is heard to ensure the latches engage.

