

## Transmitting Documents


### Number of Pages

---


This feature allows you to set the total number of pages in a Direct Send job for the current job. You do not need to select this feature for Memory Send since the machine automatically totals the number of scanned images. The number of pages is printed in the header by the receiving machine.

To set the Total Number of Pages:

1. Load the document face down in the Document Tray.
2. Press Direct Send.
3. Press:



4. Using the Numeric Keypad, enter the total number of pages in the job, then press **Enter**.



5. Press **Menu** to select additional fax options or, using one of the dialing methods, enter the fax number, then press **Enter**, if necessary.

The document is sent and the machine returns to the Standby Mode.