

Programming the Machine




Group nbr (1-1999):

- Using the Numeric Keypad, enter the group number you want to use to send the document, then press **Enter**.

The machine dials each number in the group and sends the document.


Deleting or Modifying a Group Number

- Open the Access Cover and press:



Enter group number
or
[<] Back to previous
[Enter] to complete

- Using the Numeric Keypad, enter the number of the Group you want to delete or modify, then press **Enter**.



Enter Group number:
1. Delete
2. Modify
3. Retain

- Select the Change option:

To delete this group, press **1**.

To modify this group, press **2**. (Refer to "Presetting Group Numbers" if necessary.)

To exit without changing this group, press **3**.

- The Enter Group Number screen redisplay. Press **Stop** to return to the Standby Mode.

Filling out the One Touch Label

As you assign phone numbers to the One Touch keys, use a pencil to fill in the location name on the One Touch Label.

