

Account Code Default Setting

The Account Code feature allows you to enter an account number when transmitting documents to a remote party. The account code is printed along with the transmission information on the Activity Report, allowing you to check the activity to that party.

1. To set the Account Code default setting:

Press:



Account code 1. On 2. Off
--

2. Select the Account Code option:

To enable the Account Code feature, press **1**.

To disable the Account Code feature, press **2**.

3. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.