

Getting Started

If you choose a resolution and the receiving machine does not have an equivalent, the WorkCentre chooses the next highest resolution compatible with the remote machine. If you do not know the remote machine's resolution capability, it is recommended that you use the Direct Send mode when Superfine Photo is selected. In Direct Send mode, the WorkCentre determines the receive resolution prior to scanning the document. The document is then scanned at the compatible receiver resolution resulting in better print quality.

To select the Scan Resolution:

Press the **Resolution** key until the required resolution mode is indicated by the Resolution LED.

Note: When the resolution LED is not illuminated, the Resolution setting is Standard.

Selecting the Scan Contrast

The Contrast setting adjusts the print darkness of the copy or transmitted document. The default contrast setting is normal on base machine. The machine returns to the default setting after each transmission.

Hint: To change the default contrast setting, press:



(See Chapter 4, "Resolution and Contrast Default Setting".)

Contrast selection	Description
Normal	For documents printed with ordinary image density. Selected when the Contrast LED is off.
Lighten	For documents with dark print that need to be adjusted to print lighter.
Darken	For documents with light or faint print that need to be adjusted to print darker.