

Dialing Methods

after 2 seconds...

Scanning into Memory	
Job number:	052
Free Memory	82%

The machine automatically dials the phone number, confirms the connection, and sends the document.

Keypad Dialing

This feature allows you to dial your destination by entering the number using the Numeric Keypad.

To dial the remote station using Keypad dialing:

1. Load the document face down in the Document Tray.

05-01-97 Thu15:47	
Ready	
Free Memory:	92%
Dial or press Copy	

2. Select the desired **Resolution** and **Contrast**.
3. Using the numeric keypad, enter the phone number and press **Start**. To enter a pause, press the **Pause** key. To enter a Charge Code, press the **Charge Code** key and enter the number after the telephone number.

Fax number (128 max): 5551515

After 2 seconds...

Scanning into memory	
Job number:	017
Free Memory:	92%