


Ringer Volume Setting

Use this feature to adjust the WorkCentre Ringer Volume. The volume range is from 1 (low) to 7 (high).

To adjust the Ringer volume:

1. Press:



Note: The current setting is displayed on the bottom right of the display.

2. Using the Numeric Keypad, enter the Ringer Volume setting from 1-7, then press **Enter**.
3. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.