

Power Saver Setting

The Power Saver function allows you to turn the power off to save power consumption. If the Power Saver function is On, a warm up period is needed before printing occurs. There are two Power Save modes with this machine, Super Power Save and Printer Power Save.

- Super Power Save - Turns all the power off to minimize power consumption. Select one of three modes, Automatic, Manual or Off:

Automatic mode: Enters the Power Saver Mode automatically when in the Standby Mode for the pre-set time period.

Manual Mode: Enters the Power Saver Mode when the Power Save key on the control panel is pressed. If the machine is in the Standby Mode when the Power Save key is pressed, it enters the Power Saver Mode immediately. If the Power Save key is pressed while the machine is not in the Standby Mode, it enters the Power Saver Mode after returning to the Standby Mode.

Off: Disables the Super Power Saver mode and the Printer Power Saver mode button on the control panel.

1. Press:



Super power save
1. Automatic
2. Manual
3. Off

2. Select the Super Power Save mode:

To select the Automatic mode, press **1**. Then, go to Step 3.

To select the Manual mode, press **2**. Then, go to Step 4.

To select Off, press **3**. Then, go to Step 4.

Programming the Machine

Entering time

Time (n-60min)

1

3. When you select the Automatic mode, using the Numeric Keypad, enter the time period (in minutes) for standby before the machine enters the Super Power Save mode automatically.
4. When you select the Manual mode or Off, select the default for the Printer Power Save mode

- Printer Power Save - Turns the printer heater off to save power consumption.

Press:



3

1

0

7

Select the Manual mode, press **2**. Then, go to Step 4.

Printer power save

1. On
2. Off

To enable the Printer Power Save mode, press **1**.

To disable the Printer Power Save mode, press **2**.

5. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.