

Group Relay Transmission

Use this procedure to send your document to up to 16 Relay Stations that are preset to a Relay Group. The Relay Stations then retransmits your document to specific End Stations that are assigned to Relay Group numbers by the Relay Stations.


To send a document via a Group of Relay Stations:

Note: *Ensure that the same System Password is programmed on your machine and each Relay Station. The password is checked by the Relay Stations at the time of transmission.*

1. Set up a Relay Group. (See “Presetting Relay Group Numbers”.)
2. Load the document face down in the Document Tray.
3. Select the desired **Resolution** and **Contrast**.

Note: *If the required Relay Group is assigned to a One Touch key, press that One Touch key.*

4. Open the Access Cover and press:



5. Enter the Relay Group number, then press **Enter**. (See “Presetting Relay Group Numbers”.)

The document is sent to each Relay Station in the Relay Group. Each Relay Station will then transmit the document to the End Stations that were specified in the Relay Group. (See “Presetting Relay Group numbers”.)