

## **Copy Mode**

---

When the machine is in the Copy Mode, the display informs about the machine status as the machine prints single or multiple copies of the document. When in the copy mode, the following information is displayed:

- The displays indicates Copying.
- Paper size
- Collate Feature — Collate On/Off
- Copies

## **Menu Mode**

---

When the machine is in the Menu Mode, the display indicates each programmable feature, and the settings selected. As you scroll through the menu, the machine prompts you for the information necessary to program each feature.

Several of the features accessed through the Direct Access Function Keys also use menu access.

For a complete overview of the programmable features, refer to the Menu Flow Map in Chapter 4.

## **PC Printing Mode**

---

Using the ControlCentre software, the WorkCentre can communicate with your PC to allow PC printing and programming of features.