

Discard Extra Setting*

When the Discard Extra Setting feature is enabled, any portion of the document, up to 10mm, that is longer than the recording area is discarded. If the excess portion is greater than 10mm, the document is printed on 2 pages. This allows for remote machines that have scanners that are slight slipping to fit the image on one page. This feature not allowed in all markets.

In some cases the lower part of the document data may be lost.

To set the Discard Extra selection:

1. Press:



Discard extra
1. On
2. Off

2. Select the Discard Extra selection:

To discard the portion of the document exceeding the recording area, press **1**.

To automatically divide oversized documents into multiple pages, press **2**.

3. The menu selection screen redisplays. Press **Stop** to return to the Standby Mode.

*Not available in all markets.