

## Programming the Machine

22. To add an additional option, go to step 8. To exit, press **1** and go to step 23 to complete the procedure.

**Speed dial:** 001  
**Press One Touch Key**  
**to enter or**  
**[Enter] to skip**

23. To link this Speed Dial Number to a One Touch key, press the desired **One Touch Key**; or to skip this step, press **Enter** .

**Note:** *If you select an assigned One Touch number, you have the option of deleting or retaining the information previously stored.*

24. To assign additional Speed Dial numbers, repeat steps 2 – 23.  
25. When you have completed the Speed Dial assignment, press **Stop** to return to the Standby Mode.


### Modifying or Deleting Speed Dial Numbers

---

Use this procedure to change or delete a previously assigned Speed Dial number. When you enter the Speed Dial number you want to change or delete, the “Speed dial number Already assigned” message displays.

To modify or delete a Speed Dial number:

1. Open the Access Cover and press:



**Enter Speed Dial Nbr**  
**or**  
**[<] Back to previous**  
**[Stop] to complete**

## Programming the Machine

2. Enter the Speed Dial number you want to modify, then press **Enter**.

<b>Speed dial number</b> <b>1. Delete</b> <b>2. Modify</b> <b>3. Retain</b>
--

3. To delete the Speed Dial number, press **1**.

To modify the number information, press **2**.

To retain the number information, press **3**.

Refer to the previous procedure, "Presetting Speed Dial Numbers," to update the speed dial information.

4. The Enter Speed Dial screen redisplay. Press **Stop** to return to the Standby Mode.

<b>Note:</b> <i>When modifying a Speed Dial number that is tied to a One Touch key, you do not have to re-apply the number to the One Touch. If you do, the machine prompts you to retain/delete the original one touch setting.</i>
--