


## Status Code Table

A status code is displayed on some reports. The Code is displayed in 3 digits to the right of the Mode symbol.



Code	Transmission Speed	Code	Line Density	Code	Encoding
0	2400 bps	0	8 pels/mm x 3.85 lines/mm	0	MH
1	4800 bps	1	8 pels/mm x 7.7lines/mm	1	MR
2	7200 bps	2	8 pels/mm x 15.4 lines/mm	2	MMR
3	9600 bps	3	—	3	JBIG
4	12000 bps	4	16 pels/mm x 15.4 lines/mm		
5	14400 bps				
6	33600 bps				