

## Setting the Machine Default Settings

### Error Correct - ECM Default Setting

Error Correction Mode (ECM) is an internationally-recognized error correction system. It enables communications with clean images since it automatically re-sends any portion of the document affected by line noise or distortion.

This feature cannot be accessed if a document is stored in memory.

**Note:** *ECM must be set to On when the 33.6K BPS Modem is installed in your machine.*

- Both the sender and the receiver must have the ECM feature to perform ECM communications.
- Communication time is longer when transmissions are affected by interference.

To set the Error Correct-ECM default mode:

1. Press:



**Error correct-ECM**  
1. On  
2. Off

2. To enable ECM, press **1**.  
To disable ECM, press **2**.
3. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.