

Setting the Receive Footer

A Receive Footer option is available which enables the WorkCentre to print a receive footer on each received page.

The Receive Footer displays the following information:

- Footer Message
- Date
- Start Time
- Transmitting Station ID
- Receiving Station ID
- Page Number

To enable the Receive Footer:

1. Press:



Receive footer
1. On
2. Off

2. Select the Receive Footer option:

To enable the Receive Footer, press **1**.

To disable the Receive Footer, press **2**.

The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.