


## Cancel Job

2. If you would like to cancel the displayed job, press

Cancel Job



Cancel this job?

Job number:

010

1. Yes

2. No

3. Press **1** to cancel the displayed job, or press **2** to return to the Standby Mode.

The machine returns to the Standby Mode.

## Cancel Job Key

---

Pending jobs can be cancelled as they are confirmed in the display. The Cancel Job key allows you to cancel the following types of jobs:


- **Incoming call** — Cancels a job currently being received.
- **Send** — Cancels an active job or a reserved Memory Send job.
- **Document in ADF** — Cancels a Direct Send job in the Document Tray.
- **Poll** — Cancels a reserved “Polling” job.
- **Document to be polled** — Cancels a “Storing a Document to be Polled” job reserved on your machine to be polled.
- **Send via Relay** — Cancels a reserved Relay transmission initiated by your machine.
- **Relay (station)** — Cancels a Relay transmission initiated by a remote machine where your machine is the Relay Station.
- **Poll a mailbox** — Cancels a “Polling a Remote Mailbox” reception job.
- **Send to mailbox** — Cancels a “Sending to a Remote Mailbox” job.

## Cancelling Jobs

To cancel a pending job:

1. Press:

*Cancel Job*



**Cancel job**  
**1. Incoming call**  
**2. Send**  
**3. Document in ADF**

**4. Poll**  
**5. Doc to be polled**  
**6. Send via relay**  
**7. Relay (station)**  
**8. Poll a mailbox**  
**9. Send to mailbox**

2. Select the type of job you want to cancel.

To cancel an Incoming Reception, press **1**.

To cancel a Memory Send transmission, press **2**.

To cancel a Direct Send transmission, press **3**. Go to step 4.

To cancel a Polling operation, press **4**.

To cancel a Document Waiting to be Polled, press **5**.

To cancel a Relay transmission, press **6**.

To cancel an Incoming Relay transmission, press **7**.

To cancel a Mailbox Polling operation, press **8**.

To cancel a Send to a Mailbox transmission, press **9**.

**Cancel job**  
**[Enter] to cancel**  
**Previous [↑]**  
**Next [↓]**

## Cancelling Jobs

The first pending job of the type selected is displayed.

**Note:** If no key is pressed within 5 seconds, the first pending job is displayed.

3. Press the  and  arrow keys to view each pending job of this type.

Type of job	→	<b>Poll one number</b>	
Remote number	→	<b>5551212</b>	
Time job was reserved	→	<b>May-01-97 05:26</b>	
Job number	→	<b>Job number:</b>	<b>043</b>

4. When the job you want to cancel is displayed, press **Enter**.

<b>Cancel this job?</b>	
<b>Job number</b>	<b>043</b>
<b>1. Yes</b>	
<b>2. No</b>	

5. To cancel the displayed job, press **1**.
- To exit this mode without cancelling a job, press **2**.

The machine returns to the Standby Mode.