


Installing the Accessories

External Telephone*

An external telephone can be connected to the WorkCentre allowing you to share a telephone line for both phone and fax activities.

To connect a telephone:

1. Connect the cord from the external telephone to the Tel Connector on the WorkCentre.



*Not available in all markets.