

Selecting the Scan Resolution

The **Resolution** key selects the scan mode for copying, transmitting, or storing a document in memory. The scan resolution can be set to one of five settings based on the type of image you are scanning.

The resolution can be changed during a transaction. To select the resolution of the first page, load the document and press the **Resolution** key until the desired resolution is indicated by the Resolution LED. To change the setting for any subsequent pages, reset the resolution before the desired page scans.

The default resolution setting is standard only on the base machine. The machine returns to the default setting after each transaction.

Hint: To change the default resolution setting, press:



(See Chapter 4, "Resolution and Contrast Default Setting".)

The following table describes the available resolution selections:

Resolution selection	Description
Standard	Use for sending normal text and graphics. Selected when the Resolution LED is off.
Fine	Use for documents with small characters (newspaper print, etc.).
Superfine	Use for documents containing very detailed print.
Photo Fine	Use for photos or documents with colors or shading with low contrast images.
Photo Superfine	Use for very detailed photos or documents with colors or shading with high contrast images.