

Redial Count & Interval Setting*

When a document is reserved in memory and a job number is assigned, the machine automatically attempts to send the document according to the redial setting.

Using this procedure, you can set the length of time between redial attempts (Interval), and the number of times your machine redials a number.

The redial interval range is from 1 to 15 minutes, and the number of redials can be set between 0 and 14 attempts.

If the Resend Stored Fax feature is active and the machine exceeds the number of redials, your document is retained in memory (see Chapter 8, "Transmitting Documents").

To change the Interval and Number of redials:

1. Press:



Redials 1. Interval 2. Number of redials

2. Select the Redial Mode you want to change:

To select Interval, press **1**, then go to step 3.

To select Number of redials, press **2**, then go to step 5.

* Not allowed in all markets.

Programming the Machine

- Using the Numeric Keypad, enter the number of minutes you want the machine to wait before redialing, then press **Enter**. You must use a leading 0.

Redials	
Interval	(01-15) min.
	01

- The menu selection screen redisplay. If you selected **1**, press **Stop** to return to the Standby Mode, or enter 06 to go to redials screen again.
- If you selected **2**, use the Numeric Keypad to enter the number of times you want the machine to redial the number, then press **Enter**. Must use leading 0.

Redials	
Redials:	(00-14):
	01

- The menu selection screen redisplay. Press **Stop** to return to the Standby Mode, or enter 06 to go to redials screen again.