

Programming the Machine

Refuse Junk Mail Setting

This feature prevents your machine from receiving documents from unknown parties. Documents are received only from those parties whose telephone numbers are assigned to your machine phonebook.

Refuse Junk Mail is effective only on incoming calls in the Auto Receive Mode. (See "Setting the Answer Mode" in chapter 6.)

To enable the Refuse Junk Mail feature:

1. Press:



Refuse junk mail

1. On
2. Off

2. Select the Refuse Junk Mail option:

To enable the Refuse Junk Mail feature, press **1**.

To disable the Refuse Junk Mail feature, press **2**.

3. The menu selection screen redisplay. Press **Stop** to return to the Standby Mode.