

Deleting One Touch Dial Numbers

To delete a One Touch number:

1. Press:



Press One Touch key
or
[<] Back to previous
[Stop] to complete

2. Press the One Touch key to delete.

One Touch key: 03
Already assigned
One Touch key: 03
XEROX

After 2 seconds....

One Touch key
1. Delete
2. Retain

3. To delete the One Touch key assignment, press **1**.
To retain the key assignment, press **2**.
4. The One Touch Setup screen redisplay. Press **Stop** to return to the Standby Mode.