

Transmitting Documents

Direct Send

When the Direct Send default transmission mode is selected, the machine first dials the remote fax machine and confirms the connection. When the connection is confirmed the machine sends each document page as it is scanned.

To send a single transmission in Direct Send Mode, refer to the “Direct Send with Memory Send Selected” procedure that follows.

To send a document using the Direct Send mode as the default transmission mode:

1. Load the document face down in the Document Tray.

| | |
|--------------------|------|
| 05-01-97 Thu15:47 | |
| Ready | |
| Free Memory | 100% |
| Dial or press Copy | |

2. Select the desired **Resolution** and **Contrast**.

Note: You may select another option for this job. Refer to the selected option for the procedure.

3. Using one of the dialing methods, dial the fax number and press **Start**, if necessary. (See Chapter 7, “Dialing Methods”.)

| | |
|-------------|-----|
| Dialing | |
| Job number: | 022 |
| 5551212 | |

The machine assigns a job number, dials the number and scans the pages as they are transmitted.