

# Release Notes

## Phaser 3160

### SPAR Release V1.50.00.63



Release Date: July 2012

#### Software Release Details

Component	Version
Firmware	OS: V1.50.00.63 05-16-2012 Engine: 1.00.07 PCL5e: 5.98.02.01 11-05-2010 PCL6: 5.95 06-02-2009 Network: V4.01.04 08-17-2009



#### Purpose

This Release addresses the following:

This release made enhancements / software improvements to support the manufacturing process

This Release DOES NOT include any SPAR or SFR fixes since the last manufacturing release 1.50.00.62.

#### I. Installation Notes

The Software is located on xerox.com.

#### II. Installation Instructions

##### **CentreWare Internet Services (CWIS) Procedure for upgrading firmware on a Phaser 3160 printer:**

1. Copy the Phaser 3160 firmware file to your computer. If the file is in a .zip format, unzip the file.
2. Open Internet Explorer or other Browser application. Type in the IP address of the Phaser 3160 to be upgraded (example: "<http://12.345.67.890/>"). Press the Enter key to connect to the printer.
3. Select the Print button. Select File Download under Print options (left side of screen).

4. Within the "File Download" screen, select "Browse" to access the location on your computer where you have placed the firmware file. Select the file and Enter.
5. Select the blue button below the filename window to begin the file download to the printer. A "pop-up" window will be displayed showing the file download status.
6. Once the file has been downloaded to the printer, the screen will show "End of Download". Select OK to close the message window.
7. The firmware file will be installed on the printer.
8. You may print a Configuration Page to confirm the new firmware file version has been installed. To do this from the browser window select "Print -> Print Configuration Pages", select "Printer Configuration Page" then the blue button. Please refer to the "Firmware Version" title on the printed configuration page.
9. You can now close the CWIS window.