









printer

### Drum Cartridge




Cartouche de tambour • Cartuccia tamburo • Trommelkartusche • Cartucho del tambor • Cartucho do fotorreceptor • Drumcassette • Trumkassett • Trommelkassett • Tromlemodul • Rumpukasetti • Картридж барабана • Tisková jednotka • Wkład bębna • Dobkazetta • Dram Kartuşu • Φύσιγγα τυμπάνου • 硒鼓盒 • 滾筒匣 • 드럼 카트리지


See the instructional video at [www.xerox.com/support](http://www.xerox.com/support)




7



8



9



10

