



## Repacking Instructions

Instructions d'emballage • Istruzioni per l'imballaggio • Hinweise für das Verpacken • Instrucciones de reembalaje • Instruções para reembalagem • Instructies voor opnieuw inpakken • Instruktioner för ompaketering • Instruksjoner for pakking • Instruktioner om genindpakning • Pakkausohjeet • Инструкции по повторной упаковке • Pokyny pro opětovné zabalení • Instrukcje przepakowywania • Csomagolási útmutató • Οδηγίες επιστροφής προϊόντος • 重新包装说明 • 重新包裝說明 • 재포장 지침



**Do not remove the toner cartridges.**

Ne retirez pas les cartouches de toner de l'imprimante.






Non rimuovere le cartucce di toner.








Entfernen Sie die Tonerkartuschen nicht.

No retire los cartuchos de tóner.


Não remova os cartuchos de toner.

Verwijder de tonercassettes niet.






13




14




14.2


14.1




15



16



16.1



16.2