


Enhanced High Capacity Stacker (EHCS) Cooling Fan Operating Instructions

Enhanced High Capacity Stacker (EHCS) Cooling Fan Switch Location

A cooling fan has been installed in your EHCS, with an ON/OFF power switch.

Figure 1 shows the location of the fan power switch.

1. The cooling fan is only required to be ON when using coated paper with weights of 210gsm or greater.
2. For coated paper weights below 210gsm and uncoated papers the fan should be in the switched OFF position.



**Figure 1 – EHCS Cooling Fan Power Switch
Location**