

Product Xerox 4110 / 4590 Copier Printer “How Do I?” guide for Operators	Title Print on Carbonless Paper
	Date May 2007
	Page 1 of 1

How to Print on Carbonless Paper

Depending on whether you are copying or printing & which tray you are using, will decide if you use the straight collated carbonless** or Reverse collated carbonless paper.

If you are copying, you can use straight or reverse collated in any tray as you can stipulate face up or face down output.

However, with printing, you cannot stipulate this. If you are using trays 1, 2, 3, or 4, with printing, use the reverse collated carbonless paper. If you are using tray 5, 6 or 7, then you can use the straight collated carbonless paper.

NOTE: "XEROX Premium Digital **Carbonless** stock is not intended for sole usage, nor is it recommended to exceed this monthly print volume without interim service." (Monthly print volume not to exceed 125K.)

**"NCR" is a brand name of carbonless paper and is a commonly used term when referring to carbonless paper

Special cleaning procedures are required. Please contact your Xerox Service Representative.