

New firmware update containing the latest improvements is available for your VersaLink.

Supported Products:

Versalink: C400, C405, B400, B405, C7000, C7020/C7025/C7030, C500/C600, C505/C605, B600/B610, B605/B615, B7025/B7030/B7035

Note: Please print a configuration page before updating to retain a copy of your current network settings.

To Print a Configuration Report

1. At the printer control panel, press the **Home** button.
2. Touch **Device > About > Information Pages**.
3. Touch **Configuration Report**.
4. To return to the Home screen, press the **Home** button.

Updating the Printer Software

Notes:

- Software installation begins several minutes after you submit the software to the printer.
- When installation begins, the Embedded Web Server is disabled.
- You can monitor the installation progress from the printer control panel.
- When the installation completes, the printer restarts and prints a Software Upgrade Report.

Checking the Software Version

You can update your printer when Xerox releases a new version of printer software or firmware. Before you download and install new software, determine the current software version installed on your printer.

To determine the firmware version from the Embedded Web Server:

1. In the Embedded Web Server, click **System**.
2. Click **Software Update**.
3. In the Software Update area, view the Current Version.

To determine the firmware version at the printer control panel:

1. At the printer control panel, press the **Home** button.
2. Touch **Device > Software Update**.
3. For Current Version, view the version number.

Enabling Upgrades

1. In the Embedded Web Server, click **System**.
2. Click **Software Update**.
3. In the Software Update area, click **Enable**.

Installing Software Manually

This method explains the steps for installing software that you have downloaded from the Xerox website.

1. If needed, print the Configuration Report.
 - a. At the printer control panel, press the **Home** button.
 - b. Touch **Device > About > Information Pages**.
 - c. Touch **Configuration Report**.
 - d. To return to the Home screen, press the **Home** button.
2. At your computer, download the software to install.
3. Click the file you downloaded and unzip the contents.
4. Open a Web browser, then type the IP address for your device.
5. Log in as administrator, then click **System > Software Update**.
6. In the Update with File Specified area, click **Select**.
7. Navigate to the location where you downloaded the file, then select the .bin file.
8. Click **Install Now**