

Xerox DocuPrint C20
XP Printer Postscript Driver Installation Instructions

*** Removal of any C20 drivers prior to this installation is recommended ***
*** If the "Found New Hardware" window appears, click on "cancel" ***

1. Save the appropriate printer driver file to your desktop or other convenient location on your computer.
2. Attach a parallel communication cable from the printer to the computer.
3. Double click on the printer driver file saved to your desktop (or other convenient location on your computer) from the Xerox web site.
4. Click "Unzip" (to copy the print driver files to the C:\Windows\Temp folder)
5. Click "OK" and then click "Close".
6. Click on "Start", then click "Control Panel", then click "Printers and Other Hardware", then click "Add a printer".
7. After the "Add Printer Wizard" window appears, click "Next".
(If "Found New Hardware" window appears click on "cancel")
8. Select "Local printer attached to this computer", uncheck the "Automatically detect and install my plug and Play printer" box if it is checked then click "Next".
9. Click "Next" (to select LPT1 as the printer port to be used).
10. Click "Have Disk".
11. Click "Browse" and click on the down arrow to the right of "Look in:", select "Local disk (C:)" (or the folder you directed the files to be copied to), then double click "Windows", double click "Temp", select Lexpst and then click "Open".
12. Click "OK" (to accept the path displayed).
13. Select your printer from the list and click "Next".
14. If the "Use Existing Driver" screen appears, select "Replace existing driver" then click "Next". Click "Next" (to accept the name and make this your default printer).
15. Click "Next" (to automatically print a test print).
16. Click "Finish".
17. Select "Continue Anyway".