










PHASER[®] 2135

NETWORK COLOR PRINTER

IMAGING DRUM • CILINDRO DE IMPRESIÓN • FOTORRECEPTOR
DE IMAGEM • TAMBURO FORMAZIONE IMMAGINI • BILDTRÖMMELE •
IMAGING DRUM • TAMBOUR D'IMAGERIE • AVBILDNINGSTRUMMA •
Светочувствительный барабан • 成像鼓 • 成象鼓 •




7




<http://www.xerox.com/officeprinting/recycle>


8




9




10




11



12



13



14

