











Repacking Instructions


printer

Instructions d'emballage • Istruzioni per l'imballaggio • Hinweise für das Verpacken • Instrucciones de reembalaje • Instruções para reembalagem • Instructies voor opnieuw inpakken • Instruktionser för ompaketering • Instruksjoner for pakking • Instruktionser om genindpakning • Pakkausohjeet • Инструкции по повторной упаковке • Pokyny pro opětovné zabalení • Instrukcje przepakowywania • Csomagolási útmutató • Yeniden Paketleme Yönergeleri • Οδηγίες επανασκευασίας προϊόντος • 重新包装说明 • 重新包装说明 • 재포장 지침







11




12




13



14



15



16

