


Xerox® Phaser® 6700



Install Hard Drive • Installer le disque dur • Installare il disco rigido • Festplatte installieren • Instalar la unidad de disco duro


Instalar unidade de disco rígido • Vaste schijf installeren • Installera hårddisk • Installer harddisk • Asenna kiintolevy

Installere Kiintolevy • Установка жесткого диска • Nainstalujte pevný disk • Zamontuj twardy dysk


Merevlemez-meghajtó behelyezése • Sabit Diski Takma • Εγκατάσταση σκληρού δίσκου • 安装硬盘 • 安裝硬碟

하드 드라이브 설치


1




2





3



4



5

5**6****7**

Confirm installation

Confirmez l'installation
Confermare l'installazione
Installation bestätigen
Confirmar instalación
Confirmar instalação
Installatie bevestigen
Bekräfta installation
Bekreft montering
Bekræfte installation
Vahvista asennus
Подтвердите установку
Potvrđit instalaci
Potwierdź instalację
Telepítés jóváhagyása
Yüklemeysi Onayla
Επιβεβαίωση εγκατάστασης
确认安装
確認安裝
설치 확인

Print Configuration Report

Imprimez le relevé de configuration
Stampa rapporto di configurazione
Konfigurationsbericht drucken
Imprimir informe de configuración
Imprimir relatório de configuração
Configuratie-overzicht afdrukken
Skriv ut konfigurationsrapport
Skriv ut konfigurasjonsrapport
Udskriv konfigurationsside
Tulosta konfigurointiraportti

Печать отчета о конфигурации
Tisk sestavy konfigurace
Drukuj raport konfiguracji
Nyomtatáskonfigurációs jelentés
Yapılardırma Raporunu Yazdır
Kárta Secure Digital (SD)
打印配置报表
列印設定頁
 구성 보고서 인쇄

