










# Xerox® Phaser® 7800



Hard Drive • Disque dur • Disco rígido • Festplatte • Unidad de disco duro • Unidade de disco rígido • Harde schijf • Hårddisk  
 Harddisk • Kiintolevy • Жесткий диск • Pevný disk • Twardy dysk • Merevlemez-meghajtó • Sabit Disk • Σκληρός δίσκος  
 硬盘 • 硬碟 • 하드 드라이브



**6****7****8****x4****9****10****11****12**