

Firmware Installation Instructions

Overview

The purpose of this document is to define the procedures on downloading device firmware via the device's Embedded Web Server and USB

Supported Products:

Xerox® B225 / B235 Multifunction Printers

Xerox® B230 Printers

Xerox® B310 Printers

Xerox® B305 / B315 Multifunction Printers

Xerox® C230 Printers

Xerox® C235 Multifunction Printers

Xerox® C310 Multifunction Printers

Xerox® C315 Multifunction Printers

Installation Instructions

Upgrade can be done using the below 2 methods.


Method 1:

Manual upgrade using Internet Services

This section provides instructions to upgrade machine software over the network via Embedded Web Server.

Upgrade Steps:

- From a Web browser, enter the Xerox® device's IP address to access the device's Embedded Web Server. When prompted, login as Admin.
- Go to Settings → Device → Software Update → Upload a Software File.



- Press [Browse] to locate the software file.

Software Update

Status
Current Version: MXLSC.075.024 Check Now

Remote Services Policies
 Allow device to receive updates:
 Daily Check Time: 12:00 PM
 Installation Schedule: Daily
 Time: 09:00 PM
Save Reset

Upload a Software File
 Browse for file: Browse
Upload Reset

- Press [Upload]
- Device prompts the below popup where “xxx” shows the current version in the device and “yyy” shows the new version for which device will upgrade

Update Firmware: **xxx** → **yyy**


This operation will:

- Update the printer firmware code
- Reboot the printer

Do you still want to start this operation?

Cancel Start

- Press [Start]. Once the firmware upload is successful, below prompt displays.



Upload successful.


OK

Note: Software Installation will begin several minutes after the software file has been submitted to the machine. The installation progress can be monitored from the Local UI.


Method 2: Upgrade Using USB:

If your device is equipped with a front USB port the firmware can be updated through that port.


- Prepare the USB drive by formatting and wiping the drive
- Load the firmware onto the USB drive
- Insert the USB drive into the Front USB port of the device
- Once the USB is inserted, device displays with below options.



- Click "Print From USB"
- Select the firmware file to be installed
- Once the firmware is selected, device prompts with the below screen



- Click "Update Code". The file should begin transferring to the target device.



Note: Please do not power off the device until the firmware update is complete. This process could take several minutes to complete. Once the firmware update is completed, device comes up with new firmware