
Table of contents

Safety Notes v

Electrical Safety	v
Disconnect Device	vi
Laser Safety	vii
Maintenance Safety	viii
Operational Safety	ix
Ozone Safety	x

Notices xi

Radio Frequency Emissions	xi
FCC in the USA	xi
In Canada	xi
Safety Extra Low Voltage Approval	xii
Certifications in Europe	xiii
It's Illegal in the USA	xiv
It's Illegal in Canada	xvi
Environmental Notices for the USA	xvii
Environmental Notices for Canada	xviii

Conventions xix

Symbols	xix
Writing Style Conventions	xx

<i>Tools Mode</i>	<i>1-1</i>
Overview	1-1
Entering and Exiting Tools Mode	1-1
Entering Tools Mode	1-2
Navigating in Tools Mode	1-5
Machine Defaults and Feature Defaults	1-5
Machine Defaults 1	1-8
Initial Screen	1-9
Auto Color Calibration	1-12
What to know about screening	1-13
Run Calibration	1-16
Check Gradation	1-18
Manual Adjust	1-20
Tray Priority	1-22
System Timers	1-24
Power Saver	1-24
Screen Saver	1-26
Job Spacing	1-27
Tools Off	1-28
Auto Resume Scan	1-29
Auto Resume Print	1-30
Auto Resume Stop	1-31
Auto Resume Hold	1-32
Auditron Mode Off	1-33
Job Complete	1-34
Job Program Incomplete	1-35
Audio Tones	1-36
Productivity Setting	1-38
Auto Tray Switching	1-40
Transparency Size	1-42
Set Date & Time	1-43
Setting the Date	1-43
Setting the Time	1-44
Dual Language	1-45
Non-Standard Paper Size	1-47
Oversize Settings	1-48
Machine Defaults 2	1-49
Paper Registration Adjustment	1-50
100% Adjust	1-55
Special Tray	1-56
Additional Originals	1-57
Stored Program Access	1-58

Auto Recognition	1-59
Reduce/Enlarge Presets	1-62
Photo Reproduction Level	1-64
Color Adjust & Registration	1-65
Auto Rotation	1-67
Maximum Scan to Print Quantity	1-70
Decurler Setup	1-71
Decurler Specifications	1-71
Machine Defaults 3	1-75
NVM Read/Write	1-75
Feature Defaults 1	1-79
Color Mode	1-80
Paper Supply	1-81
Edge/Center Erase	1-82
Turning Off Edge Erase	1-82
Border Erase	1-83
Edge Center Erase	1-84
Color Shift	1-85
Output	1-86
Without a Finishing Device	1-86
Using a High Capacity Stacker	1-87
Using a High Capacity Stacker Stapler	1-89
2 Sided Output	1-91
Original Type	1-94
Chroma	1-97
Reduce/Enlarge	1-98
100% or Auto	1-98
Preset/Variable	1-99
Image Shift	1-100
Color Balance	1-104
Lighten/Darken	1-105
Feature Defaults 2	1-106
Sharpness	1-107

<i>Auditron</i>	<i>2-1</i>
Overview	2-1
Authentication	2-2
Initialization	2-4
Create/Modify User Accounts	2-6
Creating a User Account	2-7
Modifying a User Account	2-9
Changing the Tools Mode Password	2-10
Creating a Password for the Auditron Mode	2-11
Review User Accounts	2-13
Review General Accounts	2-15
Review Printer Job Account	2-17
Review Service Prints Account	2-18