

Table of contents

Introduction	1-1
Conventions	1-1
Symbols	1-1
Writing style conventions	1-2
Electrical safety	1-3
Disconnect device	1-4
Laser safety	1-4
Maintenance safety	1-5
Operational safety	1-6
Ozone safety	1-7
Notices	1-7
Radio frequency emissions	1-7
FCC in the USA	1-7
In Canada	1-8
Safety extra low voltage approval	1-8
Certifications in Europe	1-8
It's illegal in the USA	1-9
It's illegal in Canada	1-11
Environmental notices for the USA	1-12
Environmental notices for Canada	1-13
Product recycling and disposal	1-13
Tools Mode	2-1
Overview	2-1
Entering and exiting Tools Mode	2-1
Entering Tools Mode	2-2
Navigating in Tools Mode	2-6
Machine Defaults and Feature Defaults	2-7
Machine Defaults 1	2-10
Initial Screen	2-11
Auto Color Calibration	2-14
What to know about screening	2-14

Run Calibration	2-17
Check Gradation	2-19
Manual Adjust	2-21
Tray Priority	2-23
System Timers	2-24
Power Saver	2-24
Screen Saver	2-26
Job Spacing	2-27
Tools Off	2-28
Auto Resume Scan	2-29
Auto Resume Print	2-30
Auto Resume Stop	2-31
Auto Resume Hold	2-32
Auditron Mode Off	2-33
Job Complete	2-34
Job Program Incomplete	2-35
Audio Tones	2-36
Productivity Setting	2-37
“Heavyweight” productivity setting- mode 1	2-38
“Lightweight” productivity setting- mode 2	2-39
“Auto” productivity setting- mode 3	2-40
Auto Tray Switching	2-41
Transparency Size	2-43
Set Date & Time	2-44
Setting the Date	2-44
Setting the Time	2-45
Dual Language	2-46
Non-Standard Paper Size	2-47
Oversize Settings	2-48
Machine Defaults 2	2-49
Paper Registration Adjustment	2-50
100% Adjust	2-55
Special Tray	2-56
Additional Originals	2-57
Stored Program Access	2-58
Auto Recognition	2-59
Reduce/Enlarge Presets	2-62
Photo Reproduction Level	2-64
Color Adjust & Registration	2-65
Auto Rotation	2-67
Maximum Scan to Print Quantity	2-70
Decurler Setup	2-71
Decurler Specifications	2-72

Machine Defaults 3	2-75
NVM Read/Write	2-75
Feature Defaults 1	2-79
Color Mode	2-80
Paper Supply	2-81
Edge/Center Erase	2-82
Turning Off Edge Erase	2-82
Border Erase	2-83
Edge Center Erase	2-84
Color Shift	2-85
Output	2-86
Without a Finishing Device	2-86
Using a High Capacity Stacker or Enhanced High Capacity Stacker	2-87
Using a High Capacity Stacker Stapler	2-89
2 Sided Output	2-91
Original Type	2-94
Chroma	2-97
Reduce/Enlarge	2-98
100% or Auto	2-98
Preset/Variable	2-99
Image Shift	2-100
Color Balance	2-104
Lighten/Darken	2-105
Feature Defaults 2	2-106
Sharpness	2-107

Auditron **3-1**

Overview	3-1
Authentication	3-2
Initialization	3-4
Create/Modify User Accounts	3-6
Creating a User Account	3-7
Modifying a User Account	3-9
Changing the Tools Mode Password	3-10
Creating a Password for the Auditron Mode	3-11
Review User Accounts	3-13
Review General Accounts	3-15
Review Printer Job Account	3-17
Review Service Prints Account	3-18

