





**To install a Hot Fix:**

1. Exit the Spire CXP3535 color server application.
2. Copy the specific Hot Fix to the Spire desktop.
3. Double-click the Hot Fix to install.
4. If you are prompted to restart your computer, click **OK**.

**Note:** Repeat this procedure for every Hot Fix.