

The Document Company

XEROX

DC220/230ST Banyan VINES® Quick Install

Installation Requirements:

Ensure that the PCPrint option has been installed and configured on your VINES server.

Before Installation:

Use the Banyan VINES MANAGE utility to:

- Create a StreetTalk Name and Password for the DC220/230.
- Create a Print Service Name for the DC220/230.
- Set the Destination to the StreetTalk Name.
- The Destination Type for the DC220/230 should be set to PCPRINT.

Record the following information for use during setup at the DC220/230:

StreetTalk Name: _____

StreetTalk Password: _____

Print Service Name: _____

- 1.** Connect the DC220/230 to your network outlet or cable.

- 2.** Enter System Administrator Setups:

- a)** Press the **[Access]** button on the Control Panel.
- b)** Enter the System Administrator password by typing **#22222** (**# key and 22222**) on the keypad and pressing **[Enter]** on the screen.

Note: #22222 is the factory default password and may be changed by your Xerox service representative to suit your needs.

- 3.** Access the Network Setups screen:

- a)** On the screen display, press **[Print Setups]**.
- b)** Press **[Network Setups]**.
- c)** Press **[Additional Setups]** at the top right of the screen display.
- d)** Press **[Banyan VINES]**.

- 4.** Enable Banyan VINES:

- a)** Press **[Enablement]**.
- b)** Press **[Enabled]**.

- 5.** Select the appropriate interface for your network:

- a)** Press **[Interface]**.
- b)** **Ethernet** is displayed.

- 6.** Enter the StreetTalk Name:

- a)** Press **[StreetTalk Name]**.
- b)** Press **[Edit]** and use the keyboard on the screen display to enter the full assigned name exactly as it was previously entered.
Example: (StreetTalk Name)@ (Group)@(Organization) could be Printer1@DSSC@XRX.

Note: Additional characters are available by pressing the Change Keyboard button in the upper right corner of the screen.

- c)** Press **[Save]**.

The Document Company

XEROX

DC220/230ST Banyan VINES® Quick Install

7. Enter the StreetTalk Password:
 - a) Press **[StreetTalk Password]**.
 - b) Press **[Edit]** and use the keyboard on the screen display to enter the assigned name exactly as it was previously entered. Case sensitivity applies.
 - c) Press **[Save]**.
8. Enter the Print Service Name:
 - a) Press **[Print Service Name]**.
 - b) Press **[Edit]** and use the keyboard on the screen display to enter the assigned name exactly as it was previously entered.
Example: (Print Service Name)@
(Group)@(Organization) could be
PrintService1@DSSC@XRX
 - c) Press **[Save]**.
9. Press **[Save]**.
10. Press **[Exit]**. The DC220/230 will reboot and print a configuration sheet in approximately 3 minutes.
11. Check the settings on the configuration sheet against those that were set up in MANAGE.
12. At the client, install print drivers and map the printer in the usual manner. Refer to the CentreWare® manual, *Getting Started with Print and Fax Services* for additional information.

Additional information on the Banyan VINES setup can be found in the *DC220/230 System Administration Guide*.