



Fig. 1-1
Press **Log in/Out**.




Fig. 1-3
Press **Confirm**.




Fig. 1-5
Press **Login Setup / Auditor Administration**.




Fig. 1-2
Enter Password.




Fig. 1-4
Press **System Settings**.




Fig. 1-6
Press **Login Setup / Auditor Mode**.

XEROX®

DocuColor 240 / 250

Quick Start Guide




Fig. 1-7
Press **Local Machine Access**.




Fig. 1-9
Press **Create / Check User Accounts**.




Fig. 1-8
Press **Save**.




Fig. 1-10
Select 0001 (Not in use). Press **Create / Delete**.






Fig. 2-1
Enter UserID.



Fig. 2-3
Press **Password**.




Fig. 2-5
Enter Password.




Fig. 2-2
Press **Save**.




Fig. 2-4
Press **Keyboard**.




Fig. 2-6
Press **Save**.




Fig. 2-7
Press **Keyboard**.




Fig. 2-9
Press **Save**.




Fig. 2-8
Re-enter Password.




Fig. 2-10
Press **Save**.

XEROX[®]

DocuColor 240 / 250

Quick Start Guide






Fig. 3-1
Press **Account Limits**.




Fig. 3-3
Select **Free Access**. Press **Save**.




Fig. 3-5
Press **Close**.




Fig. 3-2
Select **Color Access**.




Fig. 3-4
Press **Close**.




Fig. 3-6
Press **Close**.




Fig. 3-7
Press **Close**.




Fig. 3-9
Machine reboots after changes are made.




Fig. 3-8
Press **Exit**.

XEROX[®]

DocuColor 240 / 250

Quick Start Guide

